

ClearSonic GoboPac 30 Instructions

Parts Included: (1) A2436x2, (2) S2233, (8) Velcro pcs

1. Remove paper masking from A2436x2 ClearSonic Panel
2. Attach Velcro approximately 3" from the corner of each panel in the A2436x2 (see picture). Allow Velcro to set-up overnight before attaching SORBER baffles to ensure a more permanent bond.
3. Attach S2233 SORBER baffles.

Additional clear panels and SORBER baffles can be added to create a complete enclosure if more isolation is needed.

www.clearsonic.com
1-800-888-6360

