

AgSolutions Front Wear Kits MOUNTING INSTRUCTIONS

PRODUCT DESCRIPTION

A sleek, highly durable plastic replacement wear strips for longer life on poly corn heads. Designed to prevent premature wear or repair already damaged snouts. Each Kit includes 1 left strip + 1 right strip + mounting hardware.

1. Always be sure header is in lock or safe position before working under or around header.

2. Remove Allen head bolt one side at a time then insert the front wear part underneath the outside bolt and washer as shown.



3. Using a 3/16 drill bit drill out into the snout through the predrilled part as shown and insert the hardware provided do not over tighten as this could affect the strength of the wear part.





4. Final product should look as shown.

