



877-TUB-CAST

**Ekopel 2K
Bathtub Refinishing Kit**

Application Instructions

GLOVES ARE RECOMMENDED

Tips:

Warm the bathroom to 75 degrees fahrenheit for a minimum of 12 hours prior to application. This can be best accomplished by placing a portable heater inside the bathtub and leaving the bathroom door closed.

Fill large chips if necessary with a high-quality auto body filler after the tub is fully cleaned.

1. Sand down smooth or use paint stripper to remove previously applied coatings.
2. Remove ALL caulking or silicone from tub edges with razorblade **(Wash area with alcohol.)**
3. Scrub and wash tub with Lysol Power Toilet Cleaner. Fully dry tub with blow dryer/ heat gun.
4. Tape drain off with masking tape. For extra protection build a tape dam 2 inches from drain.
5. Tape around tub walls. Tape off the floor with paper plastic. **(Tape 1/8 inch onto the tub with duct tape for best results. This will help prevent dripping onto the floor.)**
6. Mix all Part A and Part B by hand **(10 minutes wait 5 minutes mix another 2-3 minutes.)**
7. Bend container in half and begin pouring from the top of the tub.
8. Pour whole container on inside 3 walls then scoop excess materials back into pail.
9. Using foam roller push excess material from the top rail of tub using light pressure. Moving material in pooling areas over any missed stops on walls.
10. Pour all scooped material onto front rail, rub roller with light pressure to push material to flow on inside and outside tub walls. Scoop extra and re-pour if needed.
11. Move material up tub wall. Roll outside tub skirt and any further missed areas.
12. Level out and remove excess from bottom of tub. Remove tape from walls.
13. Use Heat Gun or Hair Dryer to pop micro foam bubbles. This prevents staining while it oxidises. Then remove tape.
14. After 1 hour remove tape dam. Hourly scoop off / wipe excess material off drain / floor tape.
15. Wait until material stops moving onto drain area, removing remaining tape **(After 4-6 hours.)**
16. Remove wet Ekopel with alcohol or acetone if needed.
17. Remove tape, wait 24-36 hours for use.

[Follow Our Full Video Demo](#)

[YouTube: Refinished Bath Solutions](#)

[Also on our website: refinishedbathsolutions.com](http://refinishedbathsolutions.com)

EMERGENCY AND FIRST AID - IF THIS PRODUCT COMES IN CONTACT WITH EYES, FLUSH WITH LARGE AMOUNTS OF WATER FOR AT LEAST 15 MINUTES AND CONSULT PHYSICIAN IF IRRITATION PERSISTS. IN CASES OF SKIN CONTACT, WASH WITH SOAP AND LARGE QUANTITIES OF WATER AND REMOVE SAT - URATED CLOTHING. IF BREATHING DIFFICULTIES, DIZZINESS OR LIGHTEADEDNESS OCCUR WHEN WORKING IN AREAS WITH HIGH VAPOR CONCENTRATIONS. VICTOM SHOULD BE REMOVED TO AIR THAT IS FREE FROM VAPORS. IF VICTOM CONTINUES TO EXPERIENCE BREATHING DIFFICULTIES OXY-GEN SHOULD BE ADMINISTERED UNTIL MEDICAL ASSISTANCE CAN BE RENDERED. IF BREATHING STOPS BEGIN ARTIFICIAL RESPIRATION AND SEEK IMMEDIATE MEDICAL ATTENTION. IF THIS PRODUCT IS SWALLOWED. DO NOT INDUCE VOMITING SEEK IMMEDIATE MEDICAL ATTENTION.