FOOT TRIM

Install in floor of boat under console in a position which is best suited for the operator. Wiring Instructions:

- Connect <u>PURPLE</u> wire from <u>HOT TRIM</u> to power or common wire in trim cable.
- Connect <u>BLUE</u> wire from <u>HOT TRIM</u> to up or out wire in trim cable.
- Connect GREEN wire from HOT TRIM to down or in wire in trim cable.



