

Can-Am X3 JVC Lower Mount

Compatible with all Can-Am X3 models.

Parts List: Two ½" in. bolts with nylon nuts

Need Help? Call Tech Support: (480)-616-2299

Email: info@utvstereo.com

Go to utvstereo.com for colored installation pictures & YouTube videos.



INSTRUCTIONS

Step 1: Place mount on the face of the head unit.

Step 2: Slide back plate onto the back of the head unit. (Back plate should be provided with your head unit)

Step 3: Install head unit hardware to mount head unit to the UTV Stereo mount. (Reference pictures with blue arrows)

Step 4: Unscrew the factory bolts of the center console. (Reference the bottom white arrows of picture 1)

Step 5: Drill holes on both sides of the start button. (Reference top arrows of picture 1)

Step 6: Cut or drill a hole in the bottom of the center console. This is where you will feed your wires into the center console. (Reference picture 2)

Step 7: Slide mount behind the center console and install the provided hardware. (Reference picture 1)