

## Can-Am X3 Large Upper Amp Mount

Compatible with 2018+ Can-Am X3 2 seat & 4 seat models

**NOT COMPATIBLE WITH 2017 MODELS DUE TO LARGER STEERING BOX**

If your car has the front locking diff, you will need to remount the module under this amp mount.

It's simple to do.

Parts list: 1 Larger Upper Amp Mount & 7 Self Tapping Screws

Need Help? Call Tech Support: (480)-616-2299

Email: [info@utvstereo.com](mailto:info@utvstereo.com)

Go to [utvstereo.com](http://utvstereo.com) for colored installation pictures & videos.



## INSTRUCTIONS:

**Step 1:** Make sure your steering wheel is in the lowest position.

**Step 2:** Remove the 7 torx bit bolts (T30) on the driver side dash panel behind the gauge cluster.

**Step 3:** Remove the 2 torx bit bolts directly in front of the shifter knob.

**Step 4:** Remove the 3 speed clips on the dash. One speed clip is located underneath the dash next to the gauge cluster. (See picture for reference)

**Step 5:** Gently pull off cover of the location where the fuse box is located. Remove 2 torx bolts inside.

**Step 6:** Relocate the module underneath the amp mount to a new location. (Reference red description at the top of the page)

**Step 7:** Slide amp mount into position. (Reference pictures for mounting position)

**Step 8:** Feed factory wire harnesses through the provided cut outs of the amp mount. (Reference pictures)

**Step 9:** Screw in self-tappers.

**Step 10:** Mount amplifiers