

## Can-Am X3 Rockford PMX-2 & PMX-3 Lower Mount

Compatible with all Can-Am X3 models.

Parts List: Two ½" in. bolts with nylon nuts

Need Help? Call Tech Support: (480)-616-2299

Email: [info@utvstereo.com](mailto:info@utvstereo.com)

Go to [utvstereo.com](http://utvstereo.com) for colored installation pictures & YouTube videos.



### INSTRUCTIONS

**Step 1:** Place mount on the face of the head unit.

**Step 2:** Slide back plate onto the back of the head unit. (Back plate should be provided with your head unit)

**Step 3:** Install head unit hardware to mount head unit to the UTV Stereo mount. (Reference pictures with blue arrows)

**Step 4:** Unscrew the factory bolts of the center console. (Reference the bottom white arrows of picture 1)

**Step 5:** Drill holes on both sides of the start button. (Reference top arrows of picture 1)

**Step 6:** Cut or drill a hole in the bottom of the center console. This is where you will feed your wires into the center console. (Reference picture 2)

**Step 7:** Slide mount behind the center console and install the provided hardware. (Reference picture 1)