

Can-Am X3 Up-Fire Sub Box & Low-Profile Sub Box Instructions

Compatible with 2019+ 2 Seat Can-Am X3 models.

Parts List: One Up-Fire Sub Box, Four Button Head Bolts with Nylon Nuts, Eight 1" Philips Head Screws

Need Help? Call Tech Support: (480)-616-2299

Email: info@utvstereo.com

Go to utvstereo.com for colored installation pictures & YouTube videos.



INSTRUCTIONS

Step 1: Remove driver & passenger seats.

Step 2: Disconnect the driver and passenger bolts that hold the brake lines to the X3.

Step 3: Remove the side covers underneath the shifter to access the inside of the center console.

Step 4: Cut the zip tie of the fuel line to access the bolt holding the brake line in place.

Step 5: Remove the T20 screw that holds the brake line. This will give you enough slack to slide the sub box in place.

Step 6: Place driver sub box into position. (Make sure the brake line is on top of the sub box)

Repeat step 6 on passenger side if you have passenger sub box.

Step 7: Re-install the driver & passenger bolts that hold the brake line in place.

Step 8: Re-install the T20 screw that holds the brake line underneath the center console.

Step 9: Re-secure fuel line with zip tie.

Step 10: Center sub box. (Make sure sub box isn't touching any metal tubing)

Step 11: Drill 1 hole in the side of the sub box nearest the center console. (This hole will be used for speaker wire)

Step 12: Drill 4 holes through the bottom of the sub box and through the floor panel. (Reference picture 3)

Step 13: Install bolts. The bolts need to come up from underneath the box. Install washers & nuts.

Step 14: Tie a knot 2 feet from the end of the speaker wire.

Step 15: Apply silicone to the knot.

Step 16: Feed speaker wire through the hole of the sub box until the knot presses tight up against the hole.

Step 17: Make final connections to the sub-woofer, mount sub-woofer, & run speaker wire up to the amplifier.