

Polaris RZR Special Edition Sub Box

Compatible with 2014+ RZR models

NOT COMPATIBLE WITH XP PRO MODEL

Parts List: 1 sub box, 8 screws, 8 pan head bolts, 8 washers, and 8 split washers.

- 2019 & up: Comes with 2 mounting brackets.
- 2014 – 2018: Comes with 3 mounting brackets.

Need Help? Call Tech Support: (480)-616-2299

Email: info@utvstereo.com

Go to utvstereo.com for colored installation pictures & YouTube videos.



2014-2018 RZR DASH



2019+ RZR DASH



Drill hole for wire here.



2019+ RZR DASH ONLY

Instructions:

Step 1: Drill a hole for your sub speaker wire on the right side of the sub box.

Step 2: Connect wire to the sub and feed it through the hole you've drilled.

Step 3: Silicone the hole where the sub speaker wire feeds out.

Step 4: Predrill the sub with 9/64" drill bit. Silicone and mount the sub into the sub box.

Step 5: Remove factory glove box.

Step 6: Place middle bracket on top of the grab handle mount.

Step 7: Place the sub box into position and bolt the bracket onto the sub box. Do not fully tighten bolts.

(The box should be hanging by the middle mount)

Step 8: Insert plastic spacer in between the grab handle mount and the sub box. THIS STEP ONLY APPLIES TO 2019+ MODELS. (Reference the picture with arrow)

Step 9: Depending if you have the old dash or new dash, bolt on the brackets provided in the required locations and plug the holes that will not be used with the rest of the provided hardware. (Reference Pictures Above)

Step 10: Run the sub speaker wire to the amplifier.

KEY NOTES:

- Metal brackets are designed to flex when bolts are secured.
- Make sure to push sub box all the way to front of vehicle when tightening bolts.
- Make sure there is nothing on the plastic firewall area preventing sub from proper positioning.