

XT INSTALLATION

XT SHORTY INSTALLATION



Unlace the skate completely and start lacing from the **1st (bottom) eyelet**.



Continue to lace up to the **4th eyelet**.



Unlace the skate completely and start lacing from the **1rst (bottom) eyelet**.



Continue to lace up to the **4th eyelet**.



Fold XT over and clip, continue to lace normally behind the XT.



Unclip XT and you are ready to block shots.



Lace through the **4th eyelet** on the front of the XT Shorty, continue to lace normal behind the Shorty.



You are ready to block shots

XT PRO INSTALLATION



Wipe skate down to remove any dirt. Place XT PRO on skate with adhesive **backing still on** to get a visual of where your product with attach.

Wipe skate down with the provided **adhesive promoter** and allow to dry for **5 minutes**.



The XT PRO is pre-molded for your skate. For final installation and the perfect fit, the XT PRO must be re-heated and formed to your skate. **Heat one XT PRO at a time.**



HEAT GUN METHOD

- ➡ Set heat gun to 270 F
- ➡ Peel off the backing
- ➡ Apply to the skate (line up with eyelets curve)
- ➡ Apply heat evenly for 70 seconds
- ➡ Place the XT PRO on the skate and apply even pressure to mold to skate



OVEN METHOD

- ➡ Pre heat your oven to 275 F
- ➡ Peel off the backing
- ➡ Place the included parchment paper on the oven grill
- ➡ Place the XT PRO on the paper and heat for no longer than 120 seconds
- ➡ Place the XT PRO on the skate and apply even pressure to mold to skate (line up with eyelets curve)



SHOTBLOCKERS™

XT SERIES | INSTALLATION GUIDE

Thank you for choosing our XT products and welcome to Team SHOTBLOCKERS!

-Ken Belanger, Founder



You are now ready to **BLOCK ON!**