## 2003 Civic ex SI Front Kit With Stock Shock

- (1) KNOCK OFF GOLD CAP OFF SHOCK.
- ② SLIDE THREADED TUBE AND GOLD NUT ONTO SHOCK (RECESS UPWARD). REPLACE GOLD CAP AFTER HARDWARE IS IN PLACE.
- ③ DISCARD STOCK BUMP STOP AND DUST BOOT. REPLACE WITH PROVIDED BUMP STOP.
- 4 PLACE FACTORY BEARING INTO PROVIDED NEW ALUMINIUM SPRING PERCH.

