4 Runner 2014-2020 Mud Flap Installation

INCLUDES: (Rear & Front)

- (2) Front Flaps
- (6) Short (1" X #14) Self Tapping Screws
- (2) Long (2" X #14) Self Tapping Screws
- (10) Washers
- (2) Spacers



- (2) Rear Flaps
- (6) Short (1" X #14) Self Tapping Screws
- (6) Washers
- (4) Plastic U-Clips

Front Mud Flap Installation Instructions

Important: It is recommended to read through all instructions prior to starting install

NOTE: TURNING FRONT WHEELS IS RECOMMENDED TO ALLOW ACCESS FOR INSTALLATION

- 1. Remove Factory screws
- 2. Start by attaching Long Self Tapping Screw, 2 washers and spacer to flap at location D. (see fig. 1 & 2)
- 3. Fasten to factory hole in wheel well (figure 3) using a 3/8" socket or combination wrench. Then Attach 3 short self-tapping screws with washers to remaining 3 factory hole locations A, B & C. Do not tighten completely until all locations are fastened and alignment is checked.
- 4. Adjust as needed to ensure flap is aligned vertically and horizontally to your preference. Tighten all 3 screws. (NOTE: Do not overtighten Long screw to prevent over compressing rubber spacer)
- 5. Repeat above steps for opposite side.

FIGURE 1

FIGURE 2





FIGURE 3



Rear Flap Installation Instructions

Important: It is recommended to read through all instructions prior to starting install

- 1. Remove Factory screw @ Location C (see fig. 4)
- 2. Place Plastic U-Clips over factory holes in fender well lip at locations A & B.
- 3. Fasten Flap at Locations A, B & C with 3 Short self-tapping screws & 3 washers using 3/8" socket or open-end wrench (See Figure 5 & 6). Do not tighten completely until all locations are fastened and alignment is checked.
- 4. Adjust as needed to ensure flap is aligned vertically and horizontally to your preference. Tighten all 3 screws.
- 5. Repeat above steps for opposite side.

FIGURE 4

FIGURE 5

FIGURE 6









