

REK-mesh DUALY FLAPS INSTALLATION INSTRUCTIONS

PACKAGE CONTENTS:

- 2 - DUALY REAR MUD FLAPS
- 10 - ¼-20 BOLTS
- 10 - WASHERS
- 10 - ¼-20 U-CLIPS



Installation

REAR FLAPS INSTALLATION

1. Use factory-mounting locations by aligning them with the mesh cells. If factory fasteners are plastic then remove them with a flat head and pull back liner. Place u clips at factory holes behind the liner on truck body. If holes are threaded use factory bolts. Leave bolts loose in order to check if flap is level.
2. Align flaps to your desired position and tighten all mounting locations. **Make sure to mount as high up as possible.**
3. Repeat on opposite side.

