

UNIVERSAL DUALY FLAPS INSTALLATION INSTRUCTIONS

PACKAGE CONTENTS:

2-UNIVERSAL DUALY FLAPS

10 – BOLTS
10 – U-CLIPS
10 - WASHERS

1-PAPER DRILLING TEMPLATE



Installation

REAR FLAPS INSTALLATION

NOTE. If your vehicle year and make is listed on the drilling template use the following instructions:

Place paper drilling template over Right mud flap lining up the edges of template with edges of flap. Using a scratch awl (or other sharp pointed tool) to mark holes in flap for your make of vehicle.

If your vehicle is not listed on the drilling template transfer factory holes to flap then proceed with the following instructions:

1. Place uclip at factory holes behind the liner on truck body. If holes are threaded use factory bolts. Leave bolts loose in order to check if flap is level.
2. Once level fasten remaining screws and tighten. If there are not enough factory holes use provided self-drilling screws into fender lip for added support.
3. Repeat on opposite side



Note: These are general mounting guidelines. installation may vary for different model and year vehicles.

