

SUP STOW & GO SYSTEM

Model # 22-4022



PARTS LIST	
Qty	Name
1	Stow & Go Strap
2	Mounting Bracket
4	Philips Head Screw

Holds up to 100 LBS

Mounting Instructions

Tools Needed : Tape Measure, Electric Drill, $\frac{3}{16}$ " Drill Bit, and #3 Phillips Head Driver



1. Locate the wall studs where Stow & Go System will be mounted. The recommended spacing is 16" apart to allow for stud placement.
2. Use a Mounting Bracket as a template to mark the hole locations. Push a mounting screw into wall to mark the locations for holes.



Pro Tip: An old woodworkers trick is to rub the screw threads on a bar of soap for easy installation.

3. Use the $\frac{3}{16}$ " drill bit to drill both holes. It is important that these go into a wood stud.
4. Use #3 Phillips Head Driver to insert screws through bracket and into holes. Repeat for second bracket.
5. Adjust the strap lengths to gently cradle your SUP or surfboard.

Rev. 6/2018

FOR TECHNICAL ASSISTANCE OR REPLACEMENT PARTS: CALL 866.787.7369

SUSPENZ®, INC.
8725 ROSWELL ROAD #0-220
ATLANTA GA 30350



CUSTOMER SERVICE: 770-518-0045
FAX: 770-518-8507
WEBSITE: WWW.SUSPENZ.COM

Transport Instructions

When using for SUP transport, the Stow & Go System may be carried on one shoulder (as shown below) or across the body, messenger bag style. Simply adjust the straps for a comfortable fit and to ensure that your SUP or board has plenty of clearance from the ground.



FOR TECHNICAL ASSISTANCE OR REPLACEMENT PARTS: CALL 866.787.7369

OUR PLEDGE TO YOU

SuspENZ® products are warranted for life against defects in material or workmanship to the original owner. Product must be used for its intended purpose under normal conditions. Please visit www.SuspENZ.com for complete warranty information.

SUSPENZ®, INC.
8725 ROSWELL ROAD #0-220
ATLANTA GA 30350



CUSTOMER SERVICE: 770-518-0045
FAX: 770-518-8507
WEBSITE: WWW.SUSPENZ.COM