

CATCH - ALL UNIVERSAL AIRLESS CART Model # 22-9909



Holds up to 300 lbs.

Patent Pending

Suspenz is proud to join you as we
"Take the hassle out of the haul"



No tools needed...

Just grab a cold beverage of your
 choice & let's get started!



Scan to see
 Video Instructions
 for Assembly & Use
 or
 Visit Suspenz.com
 "Video & Manual" page

PARTS LIST		
Part	Qty	Name
A	2	Mag-Lite Wheel
B	1	U-Frame Bunker Bar™ with Kickstand, 2 D-Pins & Strap
C	1	U-Frame Bunker Bar™, 2 D-Pins & Strap
D	4	Mounting Block
E	1	Square Axle Shaft
F	2	Round Axle
G	2	D-Pin
H	2	Quick Release Locking Pin
I	4	Bolt
J	4	T-Nut
	1	Storage Bag (<i>not shown</i>)



The Axle components are pre-assembled for fast setup.

Rev. 3/23

SUSPENZ®, INC.
 8725 ROSWELL ROAD #0-220
 ATLANTA GA 30350



CUSTOMER SERVICE: 770-518-0045
 FAX: 770-518-8507
 WEBSITE: WWW.SUSPENZ.COM

Assembly Step 1: Connect the Bunker Bar™ Assemblies to Square Axle

1. Place *Square Axle Shaft* (yellow lettering up) on two *Mounting Blocks*.



2. Place remaining two *Mounting Blocks* on top, aligning the holes.

3. Insert the *Bolts* from the **bottom** of each *Mounting Block* pair.



4. Place the *U-Frame Bunker Bar Assembly* (the one with the Kickstand) on the right *Mounting Block* with the **Kickstand on the inside**. Secure with two *T-Nuts*. Be sure to rotate the *Bolt* so the Hex Head mates with the hex hole in the mounting block.



5. Place the *U-Frame Bunker Bar Assembly* (no Kickstand) on the left *Mounting Block*. Orient the *Bunker Bar™* so the *Yellow Bead* is at the opposite end of the cart. Each end of the cart will have a *Cam Buckle* and a *Strap Free End* with a *Yellow Bead*.

Yellow Bead



Yellow Bead

The Importance of the *Yellow Bead*

- It prevents the strap from pulling out of the end of the *Bunker Bar™* - acts like a *Stopper Bead*!
- Slide it along the strap to set the strap length to fit your boat. Now the strap is adjusted to your desired length and you are ready to go!

Assembly Step 2: Add The Wheels

2A) Slide the *Yellow Wheel* on each axle and secure with a *Quick Release Locking Pin*.



2B) There are multiple holes in the *Round Axle* allowing different wheels to be used.

This end inserted in to
Square Axle




Beach
Wheel

Yellow
Wheel


Quick Release
Locking Pin

The cart is packaged with the *Round Axle* in the correct position for the *Yellow Wheel*. **For use with Beach Wheels**, remove *D-Pin*, slide *Round Axle* to Beach Wheel hole, and replace *D-Pin*.

Understand Your *Quick Release Locking Pin*



Loop tight against pin



Replacement *Quick Release Locking Pins* can be purchased at Suspenz.com

How to Adjust my Cart (*your kayak will thank you*)

Step 1: Set *Bunker Bar* Width

1. Turn your kayak upside down. Loosen the *T-Nuts* and slide the *Bunker Bars* left-right to achieve best fit. Keep the *Bunker Bars* centered on the *Square Axle*.
2. Tighten the *T-Nuts* firmly by hand.

Once you have adjusted this cart for your kayak, note your width on the Square Axle and you are ready to go next time!



Step 2: Wheel Clearance

1. Wheel clearance should be 1/2" or more.

If greater wheel clearance is needed, contact Suspenz for optional *Extra Tall U-Frames* (adds 2").




Load my Boat on the Cart

1. Rotate *Kickstand* to down position.
2. Place cart near center of boat with *Kickstand* towards the stern.
3. Angle the cart so that the centerline of the *Bunker Bars* points to the center stern of the boat.
4. Lift bow and pivot boat to line-up with cart then lower on to cart.
5. Put *Kickstand* in the up position.



Strap my Boat to the Cart - *Now is a good time to open that cold beverage of your choice!*

1. Place straps over the top of the Boat.
2. Pull on *Strap 1 Free End* until *Strap 1 Buckle End* is on the center top of the Boat.
3. Do the same with *Strap 2*.
4. Connect *Strap 1 Free End* to *Strap 2 Buckle End* and pull to remove slack. Stop pulling when *Strap 1 Buckle End* starts to move.
5. Connect *Strap 2 Free End* to *Strap 1 Buckle End* and pull tight.
6. Return to first strap connection and tighten as necessary.



When STRAPS 1 & 2 are connected they behave as ONE long strap. This gives great flexibility to accommodate boats of many sizes.

Lastly, slide the two *Yellow Beads* to the end of each *Bunker Bar* as a reference point for the next use.

Lower Height of Cart by 2" (optional)


Most people will use the cart with the *Bunker Bars* in the High Position. This allows for greater wheel clearance and greater ground clearance. With *Bunker Bars* in the lower position, the boat does not have to be lifted as high during loading.

To configure the cart with the *Bunker Bars* in the low position:

- In steps 1.3 - 1.4 of Assembly— install the *U-Frame* on the underside of the *Mounting Blocks*. The *Bolts* are inserted from the top side of the *Mounting Block* with the *T-Nuts* screwed on the underside.

Configure Cart With Bunker Bars Crosswise (for wide loads or flat bottom boats)

1. The *Square Axle Shaft* has two thick yellow markings. Move the *Bunker Bars* so the edge of the *Mounting Blocks* touch but do not cover these marks.
2. Remove the 4 *D-Pins* that connect the *Bunker Bars* to the *U-Frames*.
3. Ease the *Bunker Bars* off each *U-Frame* taking care not to cock them.
4. Remount the *Bunker Bars* in the crosswise direction.



Convert to a Beach Wheel Cart

Add low pressure pneumatic *Beach Wheels* (6" wide) to this cart so that it will "float" over soft beach sand. *SuspENZ Beach Wheels* (SKU# 97-2022) are available.

See assembly Step 2B, use the "Beach Wheel" hole in the round axles.

