QUICK SET-UP GUIDE

CATCH - ALL UNIVERSAL AIRLESS CART

Model # 22-9909

STEP 1: Confirm you have all the parts for complete assembly



Parts List	
Qty	Name
1	U-Frame Bunker Bar ™ w/ Straps
1	U-Frame Bunker Bar ™ w/Kick-Stand & Straps
4	Mounting Blocks
4	T-Nuts
4	Bolts
1	Axle Assembly with hardware
2	Wheels
1	Storage Bag (not shown)

STEP 2: Place 4 *Plastic Blocks* on *Axle* and insert *Bolts* from underneath.



STEP 3: Press the 2 *Bunker Bar*TM frames onto the *Plastic Blocks* then secure with the *T-Nuts*



Note: *Kick-Stand* goes on the **inside** of the cart. Orient the 2nd *Bunker Bar*^{IM} (*without kick-stand*) so *Yellow Bead* is at the opposite end. Suspenz Logos on the Bunker Bars face out.

STEP 4: Remove *Quick Release Wheel Pin*, slide *Wheel* on to *Axle*, replace



ASSEMBLY is now COMPLETE

Learn how to Adjust Cart and Easy Loading Tips: Review Pages 4 & 5 of the full manual to learn how to *Adjust the Cart to Fit your Kayak* and how to *Load your Kayak onto the Cart* with ease .



Scan to see
Video Instructions
for Assembly & Use
or
Visit Suspenz.com
"Video & Manual" page

FOR TECHNICAL ASSISTANCE OR REPLACEMENT PARTS: CALL 866.787.7369

SUSPENZ®, INC. 8725 ROSWELL ROAD #0-220 ATLANTA GA 30350

Rev. 5/23

