

APE OFFROAD

2515 Bypass Rd. Flemingsburg, KY 41041
606-845-7439

Instructions for Installation and Care of Arctic Cat Prowler Full Cab Enclosure

Fits Hard Windshield

AC-PROWLER-FC05

Notice: Cab is Flammable. Do not smoke inside the cab or expose the enclosure to direct flames.

Be sure to read these instructions thoroughly before opening and installing the enclosure. The installation is best done when the temperature is 70 degrees F. or warmer. The temperature affects the adhesive Velcro, if conditions prevent installing in warmer weather it helps to store the adhesive Velcro at room temperature prior to installation.

1. Carefully unroll the Cab Enclosure on a large, flat, clean surface. Open the hood compartment and raise the bed. This will allow access to the front and rear of the vehicle for necessary installation of Velcro. Check all parts with list shown below:

2" Self-adhesive Velcro Hook:	1 each-----	120" long
" "	2 each-----	24" long
" "	2 each-----	12" long
" "	2 each-----	8" long
" "	2 each-----	6" long
" "	2 each-----	4" long
" "	2 each-----	5" long
1" Self-adhesive Velcro Hook:	2 each-----	24" long
Cab Enclosure -----	1 each	

If any parts are damaged or missing please contact customer service at (606) 845-7439.

2. Begin installation by placing the 120" adhesive Velcro strip around the wide outside edge of the front roll bar. You may need to cut the Velcro to fit around your windshield clamps. Be certain to clean the surfaces before applying the adhesive hook strips!
3. Drape the enclosure over the top of the roll cage and attach the front of the cab to the 120" Velcro strip you just installed. Be sure to center the cab correctly as this may affect fit elsewhere.
4. Working your way to the rear of the roll cage carefully fit the Cab into position. Be sure to pull the lower edge of the rear panel down between the rear of the roll cage and the front of the dump bed. Apply the two 6" Velcro strips on the back of the roll cage at the side where you see a tab is going to wrapping around to the back of the cage.
5. Next zip the doors closed. You will see three pieces of Velcro on the bottom of each door, one 6", one 12" and one 8". Match the Velcro hook strips to those already attached to the doors. The 12" strip should run along the curve of the rear fender line.
6. On the part of door in front of the zipper you will see two pieces of Velcro loop sewn in place. The 1" Velcro hook strips will run along the front fender line down to the top of the horizontal line of the floorboards. Then attach the 4" Velcro hook strips the floorboards horizontally under the 1" strip. Checking where the loop strip on the enclosure will hit the UTV before installing the adhesive strips will help to ensure a good fit

7. Now close the front hood and secure it down. It should sit on top of the bottom of the windshield. Then lower the bed into position and the bed will push in on the back of the enclosure. If it seems too tight across the rear panel, you can adjust the distance by loosening the rear of the door and repositioning the Velcro a bit.
8. To open and stow the doors, move the zipper fully rearward and fold the bottom portion of the doors up. Then begin to form a vertical roll with the door by rolling it inward from the front edge toward the rear of the door. Secure in place using the two hook and loop straps provided. Try to form a roll approximately 3-4" in diameter to assure that the door will not stick out very far while stowed.

Cleaning and Storage Recommendations:

1. Before removing the Cab for storage, make sure it is very clean in order to prevent scratching of the window panels. Clean with a soft rag or sponge using a mild liquid detergent soap and warm water solution. Never rub the windows with a dry cloth or rag! Let the Cab dry thoroughly before attempting to roll for storage.
2. It is important that the Cab be rolled up for storage rather than folding. Folding will cause damage to the windows!!! Carefully roll up the Cab similar to the way it was when it was packed at the factory. On a large, clean and flat surface, fold the doors over the rear panel first, then, interleave the top and windshield on top of the doors. Begin rolling the Cab into a roll approximately 8 inches in diameter. Put the rolled Cab back into the carton for storage at a normal room temperature. It is best not to expose the Cab to either extreme hot or cold temperatures when storing.
3. A special cleaner conditioner is available from Ape Offroad that will greatly increase the service life of the Cab Enclosure. In addition, if additional hook and loop sets are needed, they can also be ordered.

Thank you for your purchase!

Return Policy

If for any reason you choose to return this product it must be returned within **30 days from date item is received**. You **MUST** package the product exactly **as it was originally packaged from the factory to get a full refund for the product!**

The vinyl windows should never be folded when packaging in the box or for storage purposes. Lay all the windows on top of each other with the canvas folded in between and the paper (if available) on both sides of the windows.

All returned products will be inspected upon arrival at the production facility and must be in unused, factory new condition to receive refund - a 25% restocking fee will apply.

If ordered from Ape Offroad please call at 606-845-7439 to gain a return authorization number, use our preferred shipping carrier (UPS) to return the item (unless the item is defective, you are responsible for paying the shipping to return the item.) **Any returns submitted to Ape Offroad without a return authorization number will be charged a 20% restocking fee.** If ordered from one of Ape Offroad's many distributors', you must first call them and see what their return policy is. Once your item reaches our production facility, our customer satisfaction team will inspect your item to ensure unused, factory new condition. **NOTE: All windshields must be returned with the original protective film intact and not removed. Do NOT REMOVE if you have any intentions of returning the item. Refund/ replacement of a windshield will only be processed on items with original protective film or if the windshield is defective.**

Items must be properly packaged in the original shipping carton to protect them during transit and ensure your returned item arrives back factory fresh, and in new resalable condition (**any returned items that have been used, altered or damaged in any way will not be subject for a refund.**) All contents including instruction manuals, accessories, hardware, Velcro, etc. must be included in your return shipment. Only items in OEM factory new condition will be approved. Once returned items are received, credit will be issued to the original credit card/ payment method used for the purchase. Outbound shipping and return shipping cost will not be refunded. Please allow 4 to 6 weeks for your refund to be processed.

Warranty

To The Owner of this Product:

Thank you for purchasing one of Ape Offroad Cab Enclosures, Tops &/or Windshields! Below are the terms under which your product is covered under our manufacturer's warranty.

30 Day Warranty which includes and is not limited to replacing the enclosure, tops and/or windshield due to defect of the product. Please refer to the return policy in this case for more information.

1 Year Warranty includes any defect in material or workmanship within this time frame we will gladly correct the problem or replace the enclosure, tops &/or windshield. Upon submitting for the correction or replacement we will need to receive pictures of the defect in material or workmanship along with the receipt from the date of purchase.