

APE OFFROAD

2515 Bypass Road Flemingsburg, KY 41041

606-845-7439

Instructions for Installation and Care of 2009-2010 Polaris Ranger Full Cab Enclosure (ST)

PO-09/10RANGER-FC01

Notice: Do not smoke inside the cab or expose the enclosure to direct flames. Cab is Flammable.

Be sure to read these instructions thoroughly before opening and installing the enclosure. The installation is best done when the temperature is 70 degrees F. or warmer. The temperature affects the adhesive Velcro, if conditions prevent installing in warmer weather it helps to store the adhesive Velcro at room temperature prior to installation.

1. Carefully open the carton and remove the rolled up Cab Enclosure on a large flat surface that is clean and free of dirt or other material that may soil or scratch the windows of the Cab.
2. It will help to raise the bed prior to installing the cab enclosure.
3. Check over the parts included in the carton with the parts list shown below:

Velcro Hook strips:	2 each	4" long
“ “	4 each	10" long
“ “	1 each	55" long
Snap studs	21 each (1 extra)	
Cab Enclosure	1 each	

If any parts are damaged or missing please contact customer service at (606) 845-7439.

4. Begin by raising the bed of the Ranger and cleaning the metal piece that runs along the bottom. After cleaning it off affix the 55" adhesive Velcro strip centered along the back at the bottom. Now place the cab enclosure on the Ranger, it is easier if you have two people holding it up and from the front walk it up and over to get it on the roll cage. Once it is on, zip up the doors and make sure that the cab is centered and in place.
5. Now start in the rear and pull the Velcro down and attach it to the adhesive strip you have already placed along the rear. It should reach to the bottom and be centered; you may have to try a few of times until it is where you want it to be.
6. Next take the three straps on the nose and attach them to the front of the Ranger. The middle strap is longer and will go down and wrap around the bar that is in the hole along the bottom portion of the bumper. The two side straps wrap around the top bumper bar on each side. If you have a winch, it may interfere with the center strap, in this case you may not use it, the side straps are enough to hold the nose. The photo below will help show you where to place the straps.



7. Now pull the straps tight so that the edge of the nose lines up with the top of the front panel that has Polaris embossed in it. This is to ensure that the cab is in its proper location from front to back. Once this is done you will now loosen these straps and leave it be until the final step.
8. The next step will be to install the adhesive Velcro strips on both sides of the windshield. First unzip the door on the side you will start on and make sure that the Velcro tabs sewn into the cab are pulled out away from the windshield. Then place two ten inch adhesive Velcro strips on the roll cage to match up with the tabs sewn into the enclosure and pull the windshield to the side so that the edge of the windshield is at about the 45 degree mark of the roll cage and repeat for the other side. Make sure that the door zips up without any stress. This is the reason you loosened the nose so that you will pull the windshield to the sides before pulling the nose down tight. Now place the remaining two 5 inch Velcro strips on the small section of the roll cage at the bottom of the windshield and attach the tabs to it.
9. Now install the snaps along the inside of the fenders to match up with the snaps on the cab enclosure and you are ready to go. The photos below will help show you where the snaps go.



Cleaning and Storage Recommendations:

1. Before removing the Cab for storage, make sure it is very clean in order to prevent scratching of the window panels. Clean with a soft rag or sponge using a mild liquid detergent soap and warm water solution. Never rub the windows with a dry cloth or rag! Let the Cab dry thoroughly before attempting to roll for storage.
2. It is important that the Cab be rolled up for storage rather than folding. Folding will cause damage to the windows!!! Carefully roll up the Cab similar to the way it was when it was packed at the factory. On a large, clean and flat surface, fold the doors over the rear panel first, then, interleave the top and windshield on top of the doors. Begin rolling the Cab into a roll approximately 8 inches in diameter.

Put the rolled Cab back into the carton for storage at a normal room temperature. It is best not to expose the Cab to either extreme hot or cold temperatures when storing.

3. A special cleaner conditioner is available from Ape Offroad that will greatly increase the service life of the Cab Enclosure. In addition, if additional hook and loop sets are needed, they can also be ordered.

Thank you for your purchase!

Return Policy

If for any reason you choose to return this product it must be returned within **30 days from date item is received**. You **MUST** package the product exactly **as it was originally packaged from the factory to get a full refund for the product!**

The vinyl windows should never be folded when packaging in the box or for storage purposes. Lay all the windows on top of each other with the canvas folded in between and the paper (if available) on both sides of the windows.

All returned products will be inspected upon arrival at the production facility and must be in unused, factory new condition to receive refund - a 25% restocking fee will apply.

If ordered from Ape Offroad please call at 606-845-7439 to gain a return authorization number, use our preferred shipping carrier (UPS) to return the item (unless the item is defective, you are responsible for paying the shipping to return the item.) **Any returns submitted to Ape Offroad without a return authorization number will be charged a 20% restocking fee.** If ordered from one of Ape Offroad's many distributors', you must first call them and see what their return policy is. Once your item reaches our production facility, our customer satisfaction team will inspect your item to ensure unused, factory new condition. **NOTE: All windshields must be returned with the original protective film intact and not removed. Do NOT REMOVE if you have any intentions of returning the item. Refund/ replacement of a windshield will only be processed on items with original protective film or if the windshield is defective.**

Items must be properly packaged in the original shipping carton to protect them during transit and ensure your returned item arrives back factory fresh, and in new resalable condition (**any returned items that have been used, altered or damaged in any way will not be subject for a refund.**) All contents including instruction manuals, accessories, hardware, Velcro, etc. must be included in your return shipment. Only items in OEM factory new condition will be approved. Once returned items are received, credit will be issued to the original credit card/ payment method used for the purchase. Outbound shipping and return shipping cost will not be refunded. Please allow 4 to 6 weeks for your refund to be processed.

Warranty

To The Owner of this Product:

Thank you for purchasing one of Ape Offroad Cab Enclosures, Tops &/or Windshields! Below are the terms under which your product is covered under our manufacturer's warranty.

30 Day Warranty which includes and is not limited to replacing the enclosure, tops and/or windshield due to defect of the product. Please refer to the return policy in this case for more information.

1 Year Warranty includes any defect in material or workmanship within this time frame we will gladly correct the problem or replace the enclosure, tops &/or windshield. Upon submitting for the correction or replacement we will need to receive pictures of the defect in material or workmanship along with the receipt from the date of purchase.