



FALCON RIDGE

2515 Bypass Rd. Flemingsburg, KY 41041

606-845-7439

Instructions for Installation and Care of Polaris RZR XP Pro Tinted Polycarbonate Roof **PO-XP-PRO-HT01**

CAUTION: Do not smoke inside the cab or expose the enclosure to direct flames. Product is FLAMMABLE. Be sure to read these instructions thoroughly before opening and installing the enclosure. The installation is best done when ambient temperature is 70°F or warmer. If installed in cold weather, warming the adhesive Velcro strips before installation is recommended.

1. Carefully open the carton and remove the protective masking on a large flat surface that is clean and free of dirt or other material that may soil or scratch roof.
2. Check over the parts included in the carton with the parts list shown below:

1 ½" wide Adhesive Padding	1 each	120" long
1 ¼" SS Bolts	6 each	
Lock Nuts	6 each	
Large SS Washers	6 each	
Large Rubber Washers	6 each	
Small SS Washers	6 each	

- a. Begin installation by installing the adhesive padding around the sides and front of the vehicle. Make sure you don't cover the holes in the frame in the front corners. The padding goes on top of the bars as shown in the photo on the next page:



- b. Now remove all the protective film from the roof and place the front section on the vehicle
3. Now take the bolts and washers and put them in the top and through the holes in the frame that they line up with.
4. Now you are ready to take it out and enjoy. To clean the roof, always clean using a liquid of some sort to decrease the chance of scratches. We recommend using micro fiber cloths that are readily available at any dollar store. Any window cleaner will work fine; just remember to use a soft clean rag or micro-fiber cloth to clean it.