



10.1" Powerlite clearnace template

Important

Print this document at 100% scale. Cut along the dotted line and place the printed template on the inside of your wheel. This template is the profile of the assembled brake kit and is up to the installer to verify clearances and variances in wheel design. Please allow for a minimum of 0.5" clearance around the caliper profile.

