

# **AutoSock**

*...brings you home!*

## Mounting Instructions

**It could hardly be easier – The mounting of AutoSock is done in three quick steps:**

Stop the vehicle and apply the hand brake. The vehicle must not be on a slope during fitting. AutoSock should be fitted to the driving wheels. Use the orange gloves that come with your pair of AutoSock.



**1**

Begin mounting from the top of the tire working downwards. Stretch the elastic band over the top of the tire, so that the band is on the inner side of the tire. Then pull the crossing straps in order to adjust the AutoSock into the correct position - as far down as possible until the front panel becomes centered.



**2**

Once in the proper position, with only the lower part not covering the tire, move the vehicle approximately 1m forth or back.



**3**

Pull the remaining part over the tire and into position. The AutoSock will automatically self-center when you start driving.

### Warning:

AutoSock should only be used on ice and snow, and should be removed immediately once the conditions no longer requires it to be used, or when the vehicle is parked. When starting up, no one should be behind the vehicle as stones and lumps of ice, etc. could be thrown backwards with great force. Display extra caution when fitting and driving with AutoSock!