

Assembly Instructions

Zen Habitats 3.0 Enclosure: 2'x2'x2'

Parts included:

- **Preassembled screen top**
- **Preassembled bottom panel**
- **Back panel (with grommet hole)**
- **2 side panels**
- **1 acrylic door**
- **5 aluminum frames:**
 - **2 back frames (with a single channel on both sides)**
 - **1 front frame for hinge side (with a single channel on one side and a double channel on the opposite side)**
 - **1 front frame for latch side with removable sliding piece (you'll use the one that lines up with the side you want your door locks on)**
- **Substrate shield + double sided tape (optional, for loose substrate)**
- **Humidity Shield**
- **2 grommets (one for wire management, one solid for security)**
- **8 screws (IMPORTANT: Main assembly screws are often located in the frame posts, rather than the small parts bag.)**
- **1 door lock + catch**

Assembly Instructions:

Step 1: Set Up the Frame

- **Back frames:** Find the two back frames with a single channel on each side. Align with the channels on the back and side of the bottom panel. You can tell the back from the front because the front will have our Zen Habitats logo. Attach using the screws provided.
- **Front frames:** One of the two front frames will have holes for the door lock. Using the provided screws, attach this to the left- or right-side front of the enclosure that you want your door lock on. Attach the other front frame on the other side where the hinge will be on. Make sure that the sliding piece provides a door stop lip toward the back channel of the frame piece.

Step 2: Insert the Panels

- **Side panels:** Slide the two side panels into the channels on the side bars.
- **Back panel:** Slide the back panel into the channels of the back bars making sure that the grommet hole is towards the top of the enclosure.
- **Wood grain:** Make sure the wood grain on both panels is aligned for a consistent look.

Step 3: Add the Screen Top

- **Align the screen:** Place the preassembled screen top on the enclosure, making sure the channels are aligned and that the lip for the doorstop is at the front of the enclosure.
- **Attach the screen at the back two corners** using the provided screws. We'll attach the front two screws once we put the door in place.

Step 4: Slide in the Doors

- **Peel off the plastic:** Remove the plastic film from the door.
- **Align the bottom pin** in the door to the hole in the bottom door frame. Do the same with the top pin and the hole in the top screen.
- **Finish attaching the screen** by using the provided screws on the top front two corners.

Step 5: Attach the Door Lock

- **Attach lock:** Screw the door lock into the acrylic door.
- **Attach the catch** to the side door frame. Make sure the notch is facing the inside of the enclosure.

Step 6: Add the Grommet

- **Wire grommet:** If you're attaching any fixtures inside the enclosure that require a plug, or if you are using a misting system, insert the wire grommet into the hole on the back panel.
- **Solid grommet:** If you don't need wires, use the solid grommet to close the hole and secure the enclosure.

Step 7: Add the Humidity Shield (Optional)

- **Peel off the plastic:** Remove the plastic film from the Humidity Shield.
- **Place it on top:** Position the shield on top of the enclosure, sliding it to the side where your basking light isn't placed.

Step 8: Install the Substrate Shield (Optional)

- **Peel off the plastic:** Remove the protective film from the Substrate Shield.
- **Apply tape:** Use double-sided tape along the edges of the shield.
- **Attach:** Press the shield onto the front inside of the enclosure to keep loose substrate contained.

You're Done!

[Click here for video instructions.](#)

If you have any questions, feel free to reach out to Zen Habitats' support team via live chat or email at support@zenhabitats.com.