



## PAD INSTALLATION AND BED-IN INSTRUCTIONS

### STREET

Installation instructions should be followed in accordance with the application-specific brake pad installation instructions provided by the vehicle manufacturer.

### Brake Pad Installation Procedure

- Install brake pads properly. Be sure pads are securely positioned in the caliper.
- Check Brake Fluid. Flush and replace, as needed.
- Check all hydraulic parts for excess wear and tear.
- Check rotor for deep grooves or scoring. Resurface or replace rotor, as needed.
- If rotors do not need resurfacing, then contamination from the previous brake pads must be removed. Sand rotors with 130-grit sandpaper using moderate pressure. Use soap and water to clean rotor surface after sanding. Rotors should be free and clear of oil, grease and brake fluid.
- Inspect calipers for freedom of movement. Lubricate where necessary.

### Street Brake Pad Burnishing/Bedding-In Instructions

1. To break in the new components, make 6 to 10 stops from approximately 30 to 35 MPH applying moderate pressure.
2. Make an additional 2 to 3 hard stops from approximately 40 to 45 MPH.
3. DO NOT DRAG BRAKES!
4. Allow 15 minutes for brake system to cool down.
5. Your brakes are now ready for use and can be driven normally.