


## Back up cam wiring for RSNAV S3,S4 Android Systems

1. Automatic Transmission Vehicle with Audi Original Camera  
Go to Car Setting, and change the backup camera setting to Audi original
2. Automatic Transmission Vehicle with Aftermarket Camera



Do not use two wires (red and black) on the camera side.  
Connect the red wire near the yellow video side connector to the 'CCD\_PWR' bare wire of RSNAV S3, S4 main connector.

3. Manual Transmission Vehicle with Aftermarket Camera

<https://youtu.be/WsUFwQMItBQ>

See this video for the detailed instruction.

Basically, you need a 12v relay and power the camera separately from clean 12v+ source and connect the red wire near the yellow video RCA plug to 360\_DET labeled wire. You need to identify reverse light wire for the relay 86 and a clean source for terminal 30 as in the video.

4. Manual transmission Vehicle with OEM Camera

See video above link , but skip the connection of video plugs. Connect the relay's terminal 87 to the 360\_DET labelled wire on the RSNAV device using a single wire.

