



RB Components

2019 + Sprinter Van Headliner Shelf

Standard Lower Mounted

General Notes

- For the most up to date and current instructions, please visit our website at www.rbcomponents.com
- Please read all instructions thoroughly before starting installing this product.
- Headliner shelf is easier to install with the help of a second person.

Parts List

- | | |
|-------------------------------------|---|
| • (1) 63009-49 | 2019 + Sprinter Van Headliner Shelf – Small Version Raised |
| • (1) Drivers Side Front Bracket | Front Mounting Bracket (high end of bracket faces towards the rear) |
| • (1) Passengers Side Front Bracket | Front Mounting Bracket (high end of bracket faces towards the rear) |
| • (2) Rear Brackets | Rear Mounting Brackets |
| • (6) 60951-568 | 6mm x 16mm Flat Head Bolt |
| • (6) 60951-383 | 6mm Nylon Lock Nut |

Tools Needed

- 10mm open end wrench
- 10mm socket wrench
- #20 Torx (removing coat hanger)
- #30 Torx (removing sun visor and forward upper mounting screws)

Approximate Installation Time

- With two people helping (recommended)

35-45 min

Installation

- 1) Start by removing the plastic cover in the plastic hand grab as shown. Remove both side bolts using a #30 torx wrench. Once these are out you will need to remove the sun visors. These are also removed using a #30 torx wrench.



- 2) Remove the plastic clothes hanger as shown. Using a #20 torx wrench to remove this screw. Because the headliner is a tight fit to the sides of the van, we recommend using tape along the top part of the plastic as this will protect the plastic trim during installation.



- 3) Install the Left and Right Forward brackets using a #30 torx wrench. Making sure that the raised part of the bracket is facing towards the rear of the van as shown.



- 4) With the forward mounting brackets installed next will be installing the rear mounting brackets using the #20 torx wrench. To not tighten these brackets just yet as they should be able to spin out of the way. This will make it easier when the headliner shelf is lifted into place.

*****Picture shown is of the raised headliner bracket but using same concept*****



- 5) We are now ready to install the headliner shelf. This is easiest when open the passenger door and sliding the shelf in. With the help of a second person slowly raise the front part of the headliner shelf into location. Because of the tight fit to the upper part of the side molding a slight tap to get the headliner to clear the lip may be needed.
- 6) The headliner shelf should be in its desired location. Now the rear mounts can be swung under the headliner shelf as shown.



- 7) With the hardware provided secure all the bolts with the nuts on top of the headliner shelf as shown using a 10 mm socket and open end wrench to tighten headliner to the brackets.



Installation is now complete. If you have any further questions on this or any other RB Components product please feel free to reach us directly (562)802-1200.