



**RB Components
14" x 14" Magnetic Roof Vent Cover**

General Notes

- For the most up to date and current instructions, please visit our website at www.rbcomponents.com
- Please read all instructions thoroughly before starting installing this product.
- Quickly and easily covers roof vent to block out light and moderate temperature when needed.

Parts List

RB Components 07 to Present Mercedes Sprinter Van Passenger Sliding Door Bug Net

- (1) 61299-089-M 14" x 14" Magnetic Roof Vent Cover
- (8) Rare Earth Magnets To be installed to roof vent cover

Tools Needed

- Tape to hold down magnets to roof vent trim

Approximate Installation Time

- One person about 5-10 minutes.

Installation

- 1) Remove the roof vent magnetic shade from the packaging and place on the table. Place the roof vent trim over the top of the magnetic shade as shown.





- 2) Place the loose magnets on top of the vent cover. These will self-align with the magnets that are sewn into the vent cover shade.



- 3) Place ALL 8 magnets so each magnet lines up with the vent shade as shown.





- 4) Secure magnets to the roof vent trim by placing tape over each one of the magnets as shown. This will prevent the magnets from moving around when the vent trim is installed in the ceiling. The vent trim piece is now ready to install.



Installation Complete:

