



- 3) From top center working your way to the right you want to peel back about 12" of the rubber molding strip. Once pulled back, place the fabric in-between the rubber molding strip and the van, then push the rubber molding strip back into place. About $\frac{3}{4}$ -1 inch
 - a) ***Please note that zippers of the outer frame should be facing to the inside of the van.***
- 4) Repeat this step all the way down the right side of the van until you reach the bottom.





- 5) With the right side of the bug screen frame in place go back to the top center and repeat steps 3-4
- 6) The outer frame of the bug net should now be in place.
- 7) With the outer frame in place the next step is to attach bug net screen to the outer frame that is now installed (***note: before zipping screen to outer frame make sure the RB logo is facing outwards, to the back of the van***). From the inside of the van you will want to zip the very top part of the screen to the top part of the bug screen frame as shown.



8) Zip up both right and left side of the bug net screen until complete.



- 9) The bug net screen can be accessed a few different ways. Either by the center pass through (*magnetic self-closing buttons*) or by unzipping the sides.



10) The bug net screen also comes with clips at the top of the bug net. These clips are to be used when the screen is rolled up to keep out of the way. Great when loading the rear of the van.



11) The rear door bug net does not need to be removed or rolled up to have the rear doors closed.



Installation is Complete