



Installation Instructions For Rear Door Window Stuff Bags

General Notes

- For the most up to date and current instructions, please visit our website at www.rbcomponents.com
- Please read all instructions thoroughly before starting installing this product.
- Rear Door Window Stuff Bags are easier to install with the help of a second person.
- The Rear Door Window Stuff Bags can be completely or partially removed depending on the customers needs.

Parts List

- (1) Rear Door Stuff Bags
- 1/8" pop rivets

Tools Needed

- Drill
- 1/8" drill bit
- Pop Rivet Gun ([link](#))

Approximate Installation Time

- With two people helping (recommended) 20-30 min

Installation

- 1) Attach a couple of the chrome fasteners to the top corners of the window shade.
- 2) Have a second person hold the window shade making sure the shade is centered and up against the window. While doing this use a marker to mark the holes where you will need to drill into the door to mount the fastener. We will only mount the upper right and left fasteners at this time.
- 3) Remove the shade from the window and use a 1/8" drill bit to drill the holes that were marked for the upper mounting fasteners.
- 4) Using the pop rivet tool to rivet the two upper fasteners to the door.
- 5) With the two upper fasteners mounted to the door you can now install the shade to these fasteners. With the shade fastened keep the shade pressed to the window insuring the shade is aligned with the window and repeat the marking of the location of the lower corners of the shade and drill and rivet these lower fasteners into place.
- 6) The shade should now be fastened to the upper and lower part of the window and firmly in place. Repeat the installation to the side mounting fasteners making sure the shade is pressed up against the window. This will ensure that when completely installed that shade will sit against the window.



