



Start Here

STEP 1

1. Slip half of post base (1) around installed post - see Drawing 1.
2. Slip second half of post base (2) around post and align clearance holes (H) with threaded holes (T) in base.
3. Slip Phillips heads screws (3) Through holes (H) and thread them into holes (T) and tighten. Making sure post base bottom is resting on the ground.
NOTE: make sure set screws (S) at top of post base are threaded out far enough so they do not prevent the post base halves from tightening together.
4. After halves of post base are assembled tighten set screws (S) at top of base to lock post base in place.

