



Aussie Play Cleats are designed to keep your play equipment fastened safely and securely. Please ensure that all Cleats are fastened correctly with the Aussie Play Clip.

To extend the lifetime of your Aussie Play Cleats, the Aussie Play Clip must also remain fastened when your Aussie Play frame is not in use. Neglecting to do so may result in damage to the Cleat, voiding warranty.

WALKBOARD CLEAT ASSEMBLY SHEET

Enclosed within this bag

1 x Equipment Instruction Sheet, 1 x Cleat Assembly Instruction Sheet, 1 x Set of Velcro attachment pieces.

Cleat Assembly

- 1) Slide a spring washer onto each of the 8 bolts supplied.
- 2) Place 2 bolts in the corresponding holes for 1 cleat.
- 3) Slide 1 cleat over the 2 bolts.
- 4) Place a nut on the underside of the cleat and lightly tighten the bolts by hand from underneath the board.
- 5) Repeat this process for the other 3 cleats.
- 6) Make sure each cleat is aligned parallel to the walkboard and then tighten with an allen key.
- 7) NOTE: Ensure that the **cleats are fitted to the underside** of the board. I.e. If you have purchased a feature board such as a Cleated Plank or Zig Zag plank, **ensure the 'planks' are facing up.**

Notice: We use Merbau timber on all of our timber products. Merbau is a very durable timber that will last outdoors for many years. We don't use any chemicals or harmful materials to coat our timber. We use food grade vegetable oil. As such, Merbau can 'leach' tannins that may stain. Tannins will generally leach when the timber is allowed to get wet.

What can you do? Avoid getting the timber wet by packing away equipment in rainy weather. If this is not possible, avoid leaving the product on a surface that may stain (eg. Concrete). If it does get wet, wipe down the product with a disposable rag to remove any excess tannin.

Note: the leaching will stop after a period of time. This varies dependant on the timber. It is not considered a fault in the timber, it is a feature of using a natural timber product. Timbers that contains high amounts of tannin are generally more durable timbers.

