



AIRBAG MAN HEAVY VEHICLE APPLICATION GUIDE 24th APRIL 2017

Notes for Vehicle and Product Listings:

Year model cut off's can vary widely, particularly for vehicles with specialist motorbodies or RV applications, please check the chassis details for model years.

If your vehicle is not listed? - Please contact Airbag Man

Ph: 1800 air bag (1800 247 224) or 07 3889 6556

email: info@airbagman.com.au

Web: airbagman.com.au - Direct link to Heavy Vehicle:

<http://www.airbagman.com.au/products/heavy-truck-bus>

Foot Note 1: It is the vehicle owners responsibility to ensure that they comply with any relevant state or federal requirements in relation to vehicle modifications.

Foot Note 2: Airbag Man has made every attempt to assure that the air helper spring kits listed will properly fit. Chassis modifications and additional OE or aftermarket equipment may affect product fitment.

Foot Note 3: Due to new model introductions and manufacturer changes, Airbag Man reserves the right to make changes to the list without notification.

Foot Note 4: Many kits in these listings will require the vehicle and/or brackets to be drilled, trimmed to allow fitment, see notes in listings for known changes.

MAKE & MODEL	YEAR	KIT FRONT	NOTES FRONT	KIT REAR	NOTES REAR
PLEASE CONTACT AIRBAG FOR MAKES OR MODELS THAT ARE NOT LISTED - SEE MEASURE UP FORM AND CONTACT PAGE AT:					http://www.airbagman.com.au/products/heavy-truck-bus
COACHMEN					
MIRADA (Ford F53)	90-07	RR7012	Generic Kit, top bracket and chassis require drilling. Fits forward of axle. 100 mm wide springs.		
FORD					
F Series to F59			See Light Vehicle Applications		See Light Vehicle Applications
LOUISVILLE LN, LNT 8000 & 9000 SERIES "L" Series & Aeromax	ALL	RR7000AC	Generic Kit. To suit 4.0" wide springs and square top U-bolts. If vehicle does not have square top U-bolts, they will have to be purchased. Chassis requires drilling. Chassis obstructions may require relocating.		
FREIGHTLINER					
Century Class, Argosy, Coronado, Columbia	ALL		Please contact Airbag Man		
FL80	93-04	RR7020	Generic Kit, top bracket and chassis require drilling.	RR7033	Generic Kit, brackets & chassis require drilling.
HIGER					
MUNROE H7170 (7.6m)	15-17			RR7032	Generic Kit, brackets & chassis require drilling.

MAKE & MODEL	YEAR	KIT FRONT	NOTES FRONT	KIT REAR	NOTES REAR
PLEASE CONTACT AIRBAG FOR MAKES OR MODELS THAT ARE NOT LISTED - SEE MEASURE UP FORM AND CONTACT PAGE AT:					http://www.airbagman.com.au/products/heavy-truck-bus
HINO					
300 SERIES / Dutro					
300 Series 616 IFS	13-17		Front Coil Suspension - No Kit Available	RR7030	Brackets & chassis require drilling. Supplied bottom bracket replaces the current bottom u-bolt plate.
300 Series 616	2013 - 17		Please contact Airbag Man	RR7030	Brackets & chassis require drilling. Supplied bottom bracket replaces the current bottom u-bolt plate.
300 Series 716	13-17	RR7013	Generic Kit, top bracket and chassis require drilling.	RR7032	Generic Kit, brackets & chassis require drilling.
300 Series 916	07-17	RR7022	Bolt-On, No Drill	RR7032	Generic Kit, brackets & chassis require drilling.
300 Series 921	13-17		Please contact Airbag Man	RR7032	Generic Kit, brackets & chassis require drilling.
Dutro 6500	04-12		Please contact Airbag Man	RR7031	Generic Kit, brackets & chassis require drilling. Supplied bottom bracket replaces the current bottom u-bolt plate.
300 Series / Dutro	Other Models		Please contact Airbag Man		Please contact Airbag Man
500 SERIES / Ranger					
FB4J	99-00		Please contact Airbag Man	RR7031	Please contact Airbag Man
FC3J	97-01		Please contact Airbag Man	RR7031	Generic Kit, brackets & chassis require drilling.
FC6J	08-11				
FC7J 1022	12-17		Please contact Airbag Man		Please contact Airbag Man
FD	95-97		Please contact Airbag Man	RR7032	Generic Kit, brackets & chassis require drilling.
FD1J	99-10	RR7013	Generic Kit, top bracket and chassis require drilling.		Please contact Airbag Man
FD7J	11-17	RR7027	Bolt-On, No Drill	RR7032	Generic Kit, brackets & chassis require drilling.
FE7J 1426	11-17	RR7013	Generic Kit, top bracket and chassis require drilling.		Please contact Airbag Man
FG1J	06-11	RR7017	Generic Kit, top bracket and chassis require drilling.		Please contact Airbag Man
FG8J 1628	12-17		Please contact Airbag Man		Please contact Airbag Man
GD8J	2008		Please contact Airbag Man	RR7033	Generic Kit, brackets & chassis require drilling.
GH8J 1728 / 1828	Dec-17		Please contact Airbag Man		Please contact Airbag Man
GH1A 1832 / 1835	16-17		Please contact Airbag Man		Please contact Airbag Man
GT1322 4x4	-17	RR7018	Generic Kit, top bracket and chassis require drilling.		Please contact Airbag Man
500 Series / Ranger	Other Models		Please contact Airbag Man		Please contact Airbag Man
700 SERIES					
700 Series	All Models		Please contact Airbag Man		Please contact Airbag Man
INTERNATIONAL					
TRANSTAR	ALL	RR7000AC	Generic Kit. To suit 4.0" wide springs and square top U-bolts. If vehicle does not have square top U-bolts, they will have to be purchased. Chassis requires drilling. Chassis obstructions may require relocating.		
S-LINE	ALL	RR7000AC	Generic Kit. To suit 4.0" wide springs and square top U-bolts. If vehicle does not have square top U-bolts, they will have to be purchased. Chassis requires drilling. Chassis obstructions may require relocating.		
ACCO	ALL	RR7000AC	Generic Kit. To suit 4.0" wide springs and square top U-bolts. If vehicle does not have square top U-bolts, they will have to be purchased. Chassis requires drilling. Chassis obstructions may require relocating.		

MAKE & MODEL	YEAR	KIT FRONT	NOTES FRONT	KIT REAR	NOTES REAR
PLEASE CONTACT AIRBAG FOR MAKES OR MODELS THAT ARE NOT LISTED - SEE MEASURE UP FORM AND CONTACT PAGE AT:					http://www.airbagman.com.au/products/heavy-truck-bus
ISUZU					
N Series 4x2					
NLR 45/55-150	15-17	N/A	Front Coil Suspension - No Kit Available		Please contact Airbag Man
NLR 200	09-15	N/A	Front Coil Suspension - No Kit Available		Please contact Airbag Man
NNR 45/55-150	15-17		Please contact Airbag Man		Please contact Airbag Man
NNR 200	15-17		Please contact Airbag Man		Please contact Airbag Man
NPR & NQR	08-17	RR7023	Rivets need removal to fit top bracket. (Fits Avida/Winnebago on Isuzu Chassis)	RR7030	Generic Kit, brackets & chassis require drilling. May require longer U-bolts.
NPR & NQR	01-07	RR7024	Rivets need removal to fit top bracket	RR7031	Generic Kit, brackets & chassis require drilling. May require longer U-bolts.
N Series	Other Models		Please contact Airbag Man		Please contact Airbag Man
N Series 4x4/AWD					
NLS 45-150	16-17	N/A	IFS Torsion Bar - No Kit Available		Please contact Airbag Man
NLS 200	11-15	N/A	IFS Torsion Bar - No Kit Available		Please contact Airbag Man
NPS 250 & 300	97-07	RR7025	Rivets need removal to fit top bracket	RR7032	Generic Kit, brackets & chassis require drilling.
NPS 250 & 300	08-15	RR7026	Rivets need removal to fit top bracket	RR7033	Generic Kit, brackets & chassis require drilling.
NPS 45/65/75	15-17	RR7026	Rivets need removal to fit top bracket	RR7034	Please contact Airbag Man
N Series 4x4 & AWD	Other Models		Please contact Airbag Man		Please contact Airbag Man
F Series					
FRR	03-07	RR7016		RR7032	Generic Kit, brackets & chassis require drilling.
FRR 500	11-15	RR7015	Previously Fitted, Bolt on. Engine mounts require trimming.	RR7032	Generic Kit, brackets & chassis require drilling.
FRR 600	13-15	RR7013	Generic Kit, top bracket and chassis require drilling.	RR7032	Generic Kit, brackets & chassis require drilling.
FRR 107/210, 110-240, 110-260	16-17	RR7013	Generic Kit, top bracket and chassis require drilling.	RR7032	Generic Kit, brackets & chassis require drilling.
FRD 107-210, 110-260	16-17	RR7013	Generic Kit, top bracket and chassis require drilling.	N/A	AIR - Hendrickson HAS 200
FSR 32	93-94	RR7013	Generic Kit, top bracket and chassis require drilling.		Please contact Airbag Man
FSR 34	10-12	RR7013	Generic Kit, top bracket and chassis require drilling.		Please contact Airbag Man
FSR 850	14-15	RR7014	Bolt-on kit		Please contact Airbag Man
FSR 120/240, 140-240, 120-260, 140-260, 700CNG, 850CNG	16-17	RR7013	Generic Kit, top bracket and chassis require drilling.	RR7031	Generic Kit, brackets & chassis require drilling. May require longer U-bolts.
FSD 120-260, 140-260	16-17	RR7013	Generic Kit, top bracket and chassis require drilling.	N/A	AIR - Hendrickson HAS 200
FTR 150-260	16-17		Please contact Airbag Man		Please contact Airbag Man
FVD 165-260, 165-300	16-17		Please contact Airbag Man	N/A	AIR - Hendrickson HAS 230
FVR 165-260, 165-300	16-17		Please contact Airbag Man		Please contact Airbag Man
FVL 240-300	15-17	RR7035	Generic Kit, top bracket and chassis require drilling.	N/A	Single Drive with Lazy Tag Axle - Hendrickson HAS
FVZ 260-300 (FVZ1400)	99-07	RR7035	Generic Kit, top bracket and chassis require drilling.	N/A	Bogie Drive / Six rod Suspension
FX - GXD Prime Mover	13-17	RR7018	Generic Kit, top bracket and chassis require drilling.	N/A	Single Drive - Hendrickson HAS 230
F Series	Other Models		Please contact Airbag Man		Please contact Airbag Man
Giga Series					
Giga Series	All Models		Please contact Airbag Man		Please contact Airbag Man

MAKE & MODEL	YEAR	KIT FRONT	NOTES FRONT	KIT REAR	NOTES REAR
PLEASE CONTACT AIRBAG FOR MAKES OR MODELS THAT ARE NOT LISTED - SEE MEASURE UP FORM AND CONTACT PAGE AT:					http://www.airbagman.com.au/products/heavy-truck-bus
IVECO					
POWERSTAR	ALL	RR7000AC	Generic Kit. To suit 4.0" wide springs and square top U-bolts. If vehicle does not have square top U-bolts, they will have to be purchased. Chassis requires drilling. Chassis obstructions may require relocating.		
ACCO	ALL	RR7000AC	Generic Kit. To suit 4.0" wide springs and square top U-bolts. If vehicle does not have square top U-bolts, they will have to be purchased. Chassis requires drilling. Chassis obstructions may require relocating.		
KENWORTH					
ALL	ALL	RR7000AC	Generic Kit. To suit 4.0" wide springs and square top U-bolts. If vehicle does not have square top U-bolts, they will have to be purchased. Chassis requires drilling. Chassis obstructions may require relocating.		
MACK					
ALL	ALL	RR7000AC	Generic Kit. To suit 4.0" wide springs and square top U-bolts. If vehicle does not have square top U-bolts, they will have to be purchased. Chassis requires drilling. Chassis obstructions may require relocating.		
MAZDA					
T4000	89-00		Please contact Airbag Man	RR7032	Generic Kit, brackets & chassis require drilling.
T4600	92-03		Please contact Airbag Man	RR7032	Generic Kit, brackets & chassis require drilling.

MAKE & MODEL	YEAR	KIT FRONT	NOTES FRONT	KIT REAR	NOTES REAR
PLEASE CONTACT AIRBAG FOR MAKES OR MODELS THAT ARE NOT LISTED - SEE MEASURE UP FORM AND CONTACT PAGE AT:					http://www.airbagman.com.au/products/heavy-truck-bus
mitsubishi fuso					
CANTER 4x2					
Canter FEA21 (413)	11-17		Front Coil Suspension - No Kit Available		Please contact Airbag Man
Canter FEA21 (515)	11-17	N/A	Front Coil Suspension - No Kit Available	RR7031	Forward of axle. Generic Kit, brackets & chassis require drilling. Bottom bracket requires modification to suit sway bar mount. Upper bracket requires modification to suit sloped chassis rail.
Canter FEA61 (515) Tipper	11-17		Please contact Airbag Man		Please contact Airbag Man
Canter FEC81 (715) Tipper	11-17		Please contact Airbag Man		Please contact Airbag Man
Canter FEB51 (615)	11-17		Please contact Airbag Man		Please contact Airbag Man
Canter FEB71 FEC71 (815)	11-17		Please contact Airbag Man		Please contact Airbag Man
Canter FECX1 FEB91 (918)	11-17	RR7028	Generic Kit, top bracket and chassis require drilling.		Please contact Airbag Man
Canter FE 649	03-05	RR7010	Generic Kit, top bracket and chassis require drilling.		Please contact Airbag Man
Canter FE 83	05-10		Please contact Airbag Man		Please contact Airbag Man
Canter FE 84	05-10		Please contact Airbag Man		Please contact Airbag Man
Canter FE 85	05-10	RR7013	Generic Kit, top bracket and chassis require drilling. Mount Forward of axle.		Please contact Airbag Man
Canter	Other Models		Please contact Airbag Man		Please contact Airbag Man
CANTER 4x4					
Canter FG 4x4	98-16	RR7021	Bolt on kit. May require modifications to other obstructions.	RR7032	Forward of axle. Generic Kit, brackets & chassis require drilling.
FIGHTER					
FK61 / FK617 / 1024	09-17	RR7013	Generic Kit, top bracket and chassis require drilling.	RR7032	Later Models 2009-10: Sway bar bracket needs to be removed from the existing bracket and welded to the lower airbag mounting plate.
FK61 / FK617 / 1024	03-09	RR7013	Generic Kit, top bracket and chassis require drilling.	RR7032	Spacers required to be made to fit between bottom U-bolt plate and bottom air spring plate to clear irregular shape of bottom U-bolt plate.
FK62 / 1224	13-17		Please contact Airbag Man		Please contact Airbag Man
FK65 / 1227 / 1427	08-17	RR7010	Generic Kit, top bracket and chassis require drilling.		Please contact Airbag Man
FM65 / 1627	05-17		Please contact Airbag Man		Please contact Airbag Man
FM67 / 1627	05-17		Please contact Airbag Man	N/A	Single Drive with Lazy Tag Axle Option - Hendrickson HAS
FN62 / 2427	05-17		Please contact Airbag Man	N/A	6 X 4 Bogie drive - Six Rod
FN63 / 2427	05-17		Please contact Airbag Man	N/A	6 X 2 Single Drive with Lazy Tag Axle - Hendrickson HAS
FN64 / 2427	05-17		Please contact Airbag Man	N/A	6 X 4 Bogie drive - Hendrickson HAS
Fighter	Other Models		Please contact Airbag Man		Please contact Airbag Man
HEAVY					
FP54	11-17		Please contact Airbag Man	N/A	4 X 2 Single Drive - Hendrickson HAS
FV51	11-17		Please contact Airbag Man	N/A	6 X 4 Bogie drive - Six Rod Spring
FV54	11-17	RR7029	Generic Kit, top bracket and chassis require drilling.	N/A	6 X 4 Bogie drive - Hendrickson HAS
FS52	11-17		Please contact Airbag Man	N/A	6 X 4 Bogie drive - Six Rod Spring

MAKE & MODEL	YEAR	KIT FRONT	NOTES FRONT	KIT REAR	NOTES REAR
PLEASE CONTACT AIRBAG FOR MAKES OR MODELS THAT ARE NOT LISTED - SEE MEASURE UP FORM AND CONTACT PAGE AT:					http://www.airbagman.com.au/products/heavy-truck-bus
NISSAN UD					
PK	01-13	RR7028	Generic Kit, top bracket and chassis require drilling.	RR7033	Generic Kit, brackets & chassis require drilling.
OSHKOSH					
ALL	ALL		Please contact Airbag Man		Please contact Airbag Man
PETERBILT					
ALL Class 8 models with 4.0" wide front springs	ALL	RR7000AC	Generic Kit. To suit 4.0" wide springs and square top U-bolts. If vehicle does not have square top U-bolts, they will have to be purchased. Chassis requires drilling. Chassis obstructions may require relocating.		
STERLING					
All A-LINE & L-LINE Class 8 Trucks	ALL	RR7000AC	Generic Kit. To suit 4.0" wide springs and square top U-bolts. If vehicle does not have square top U-bolts, they will have to be purchased. Chassis requires drilling, chassis obstructions may require relocating.		
WESTERN STAR					
ALL	ALL	RR7000AC	Generic Kit. To suit 4.0" wide springs and square top U-bolts. If vehicle does not have square top U-bolts, they will have to be purchased. Wrapper leaf required for bottom shock mount. Chassis requires drilling, obstructions may require relocating.		

Air Control Options

Note: Kit RR7000AC includes a cab control with pressure regulator and single needle gauge that can be connected into the existing air system.

No vehicle air supply system available		Existing air system available	
Option 1	Manual inflation As standard all helper kits (Except the RR7000AC) include manual inflation schrader valves. The airbags can be simply inflated via a tyre inflation chuck.	Option 1	Manual inflation As standard all helper kits (Except the RR7000AC) include manual inflation schrader valves. The airbags can be simply inflated via a tyre inflation chuck.
Option 2	In-cab inflation control Select a 12v or 24v on-board air supply kit from below. Note: An air compressor is supplied in the AC2002-24 & AC2006-24 kits.	Option 2	In-cab inflation control Select on-board air control kit from below Note: The AC2002-24 & AC2006-24 kits include an air compressor so, are not normally used on vehicles with on-board air available.
Option 3	Other Options Explore the Airbag Man website for other available inflation systems, or speak with one of our team members for other options.	Option 3	Other Options Explore the Airbag Man website for other available inflation systems, or speak with one of our team members for other options.

Part Number	STYLE	SYSTEM DETAILS					
Air Compressors - 12v and 24v - Note that all compressors are 12v unless they say 24v (including in kits)							
Part Number	Max. Air Pressure	Description	Duty Cycle	Amp. Draw	CFM/LPM @ 0 psi	CFM/LPM @ 100 psi	
AC8110	200 psi (13.8 bar)	12v, 50% Duty Cycle @ 150psi (up to 5 gallon air tank)	50%	35 Amps	2.68/76	1.76/50	
AC8110-24	200 psi (13.8 bar)	24v, 50% Duty Cycle @ 150psi (up to 5 gallon air tank)	50%	18 Amps	2.68/76	1.76/50	
12v ON-BOARD AIR CONTROL KITS							
AC1030	Dual Control	Dual paddle switch cab controller, 12v bulb, includes tee fitting and stud for connection to existing supply					
AC1042	Single Control	Single Manual, one paddle switch c/w electric terminals, single gauge, 12v & 24v bulbs, includes tee fitting for airbags - Direct compressor control					
AC2002	Dual Control	Dual paddle switch cab controller, 12v bulb, AC8110 compressor, inflates airbags directly from compressor					
AC2006	Single Control	Single paddle switch cab controller, 12v bulb, AC8110 compressor, inflates airbags directly from compressor, includes tee fitting for airbags					
24v ON-BOARD AIR CONTROL KITS							
AC1030-24	Dual Control	Dual paddle switch cab controller, 24v bulb, includes tee fitting and stud for connection to existing supply					
AC1042	Single Control	Single Manual, one paddle switch c/w electric terminals, single gauge, 12v & 24v bulbs, incl. tee fitting for airbags - Direct compressor control					
AC2002-24	Dual Control	Dual paddle switch cab controller, 24v bulb, AC8110-24 compressor, inflates airbags directly from compressor					
AC2006-24	Single Control	Single paddle switch cab controller, 24v bulb, AC8110-24 compressor, inflates airbags directly from compressor, includes tee fitting for airbags					