

Instructions: Watch Part 1 of our H-Burner Installation Video ->

<https://www.youtube.com/watch?v=e74x2pCaZDM>



Wear protective gloves and eyewear. Prepare surface by removing all loose, scaly material and sanding rusty spots with fine sandpaper. Remove any polish or wax with lacquer thinner. DO NOT THIN PAINT. Stir paint until uniform throughout.

Brush on COLD SURFACE. FIRE MUST BE COMPLETELY OUT. At least 2 layers of paint are recommended. For best results, allow paint to air-dry for 24 hours, then heat cure to 500°F. Be sure all paint is dry before re-firing. Provide ventilation when firing for the first time after painting. Some smoke and odors are given off during this process.

Heat cure is recommended for best results. For 3+ layers, heat cure is required.