



### **COMPLETE ASSEMBLY**

1. Install a one inch PVC water line in the middle of the column.
2. Level the water bowl on your column using shims under the base of the bowl.
3. Secure the base of the bowl using 3M Scotch-Weld Epoxy Adhesive 2216 B/A as shown.
4. Use silicone to close the gap around the PVC water pipe. The water bowl should be watertight.
5. If desired, fill the bowl with decorative stone or other media.

## Still Have QUESTIONS?

Call our Customer Service Dept.  
8am - 5pm PST Monday - Friday

CALL US 1-866-578-8538  
EMAIL US [info@starfiredirect.com](mailto:info@starfiredirect.com)

## WARNING:

- It is always recommended that a professional be the one to install ANY parts or products that will be fueled by a potentially dangerous fuel source.
- Improper installation or alterations not specified in these instructions can cause injury or property damage. Read these instructions CAREFULLY and thoroughly before installing or servicing this equipment.

**PROP 65 WARNING - This product contains chemicals, including lead, known to the State of California to cause cancer and birth defects or other reproductive harm. *Wash hands after use.***