


Remove Push Pins STEP: 2

Remove the two OEM Push Pins located on the driver and passenger side of the bumper




Install Mounting Bracket STEP: 3

Remove the four OEM Bolts located under the bumper

Place Nut into Mounting Bracket TA-1, TA-2, and TA-3 this will be used to mount the Main Panel to the bumper on STEP: 4 NOTE: Push the nut all the way into the socket to prevent it from falling out


Attach and secure Mounting Bracket TA-1, TA-2, and TA-3 by re-installing the (4)OEM Bolts to its correct location



STEP: 4

Mount Main Panel

Align and secure the assembled Main Panel to the bumper using Mounting Bracket TA-1, TA-2, TA-3 with provided M6 bolt



STEP: 5

Mount the Rear Diffuser

Attach and secure Mounting Bracket TA-4 to the Side Panel with M6 25mm Bolt, Finishing Washer, and Nut **NOTE:** Push the nut all the way into the socket to prevent it from falling out

Attach the Side Panel to the Main Panel with Black Bolt and Black Nut **NOTE:** Do Not tighten Black Nut you will need to remove the Side Panel to pre-drill


Mark where Mounting Bracket TA-4 and 3/16 Spacer will be mounted to the bumper **NOTE**: Use the hole on top of TA-4 and 3/16 spacer to mark the drill location

Pre-drill into the bumper NOTE: Side Panel must be removed before pre-drilling

Install the Side Panel to the Main Panel and bumper by securing Mounting Bracket TA-4 with M6 25mm Bolt, Washer, and Nut. Secure 3/16 Spacer with M6 25mm Bolt, Finishing Washer, Washer, and Nut

NOTE: Use the sides near the wheels to secure the Washer and Nut inside the bumper

Repeat to install Passenger Side Panel to the Main Panel and bumper





INSTALLATION GUIDE

2019-2023 Toyota Supra ACM Rear Diffuser

