



# Canvas Texture Repositionable Installation Instructions

---

## Tools Needed

- Sponge
- Pencil
- Smoothing tool
- Plumb Line / Spirit Level
- Steel Spatula
- Wallpaper Knife
- Sandpaper
- Scraper

## Preparations

- Wall Patterns will be numbered at the bottom of each panel. The order of your panels will correspond with the left to right sequence.
- Clear furniture & other obstructions from work area.
- Use a warm, damp cloth or sponge to clean the wall surface and allow it to dry completely. Do not use chemicals or cleaning solutions.
- Wall should be smooth and clean. Sand any rough areas, if necessary. Prime if it has not been previously painted.
- This material can be repositioned multiple times; however, once the adhesive collects too much dust, dirt, or fibers, it can become less effective and may not stick as well to your surface.
- Turn off breaker to any electricity running to the wall you are installing on (only required for when installing around outlets or light switches). Remove & cover exposed outlets or switches to protect them from getting wet.
- Cover your flooring with tarp or absorbent drop cloth, if necessary.

## Apply Wall Covering

- Unroll the wall covering. Ensure it will cover the entire area per the measurements you supplied when ordering. Lay panels flat for a while allowing them to uncurl.
- Measure the width of your panels, and begin installation from the left wall corner. If it is not plumb (most are not), draw a plumb line out from the corner at 1" less than the width of the panel.
- Using a spirit level or plumb line, mark a straight line down the wall to act as a right side guide when applying the panel. You can repeat the plumb lines across the wall at spaces equal to the width of your panels for additional guidance, if necessary.

- This removable wall covering has a paper backing that when removed exposes the sticky adhesive. Try not to let the adhesive come together, or let the material fold up against itself. It's okay if it does, you can separate it by carefully pulling it apart. Depending on the size of the project and wall area, it may be helpful to have two people install it.
- Start at the top of your first panel and pull down approximately 4 -6 inches of the backing and crease it. Then apply the exposed adhesive area to your right side plumb line. This material can be repositioned easily. Once the right edge is flush with the plumb line, continue to slowly pull the backing downward in 4-6 inch increments, smoothing the material from the center outward as you proceed.
- As you install the second and remaining panels, butt join the left hand seam matching the design. Do not overlap the seams.
- If you need to reposition a panel, pull the wall covering away from the wall and re-set. If there are any bubbles or wrinkles, you can lightly press or smooth them out, or just peel back that area and re-apply.
- Trim the top and bottom and around any framework – Ensure that the wall covering is pushed tight into the corners and edges with your papering tool before trimming the excess. Steel rules and spatulas are ideal for neat and straight cuts. Replace your knife blade often – a dull blade may tear the paper.
- If a bubble re-appears over the next day or two, pressing lightly and rubbing can remove it. This can happen occasionally if oil, dirt, or dust is on your surface. Use a sewing pin to pop the bubble and then smooth it out with your fingers in a circular motion.

### Removal

- Beginning at the top, pull each wall covering panel slowly back on itself 180 degrees, as if you were sliding it down the wall, until it is completely removed.
- The adhesive will remain intact on the back of the wall covering allowing it to be reused elsewhere. Save the original backing paper and use this on the removed wallpaper for storage.