

CANDLE MAKING KIT

FOLLOW STEP BY STEP TO LEARN HOW TO MAKE ONE 4 OZ CANDLE!



STEP 1 : Gather your supplies:

- ✦ 2 Wicked Candle Tins
- ✦ 8 oz of Wax
- ✦ 0.5 fl oz Fragrance Oil Fuji Apple
- ✦ 0.5 fl oz Fragrance Oil Tropical Vetiver & Grapefruit
- ✦ 1 Small Saucepan*
- ✦ 1 Oven-Safe Glass or Metal Pitcher*
- ✦ Whisk or Wooden Spoon*

OPTIONAL SUPPLIES*:

- ✦ Oven Mitts
- ✦ A Wick Centering Tool, Pencil, Pen or Popsicle Stick
- ✦ Candle or Candy Thermometer
- ✦ Wick Trimmer or Scissors

STEP 2 : Fill saucepan with water until 1-inch deep and place on stovetop. Turn stove to medium heat.

Water should NOT simmer or boil.



STEP 3 : Fill pitcher with half of the provided wax. Gently place wax-filled pitcher into water.

STEP 4 : Heat wax until it reaches 175°F. Wax should fully liquify.

STEP 5 : Remove wax from heat. Add in 1 0.5 fl oz bottle of fragrance oil. Stir or whisk until fragrance is evenly dispersed. Remove pitcher of wax from saucepan.

Be cautious with hot wax. Use an oven mitt to handle hot pitcher.



*Not included in the Candle Making Kit

STEP 6 : Place candle tin on a flat, heat-resistant surface. Carefully pour candle wax into candle tin.

Use a wick centering tool or alternative to hold wick upright while wax cools.



STEP 7 : Set aside candle to cool at room temperature for at least 24 hours. Clean supplies with dish soap and warm water.

STEP 8 : Once candle is fully cooled, trim wick to be 1/4-inch.

Trim wick to 1/4-inch with a wick trimmer or scissors.



STEP 9 : Apply warning sticker to the bottom of the candle. Decorate & apply top label & wrap to side of candle.

Homemade candles make great gifts!



CANDLE TIPS:

- ✦ Write or decorate the top label before applying to the candle.
- ✦ Use a candle thermometer to monitor the temperature of the melting wax.
- ✦ Once solid, you can use a blow dryer on low power to smooth out the top of your candle.



northern lights

SCAN QR CODE FOR MORE TIPS + INFO!

