



INSTALLATION INSTRUCTIONS

PART No.

FB22278

**Jeep® JK Wrangler
Rear Mako Rear Bumper**



REQUIRED TOOLS

16mm Socket
18mm Socket
18mm Wrench

KIT CONTAINS

M12 Hex Bolt
M12 Flat Washer
M12 Lock Washer
Nut Plate

QTY

4
4
4
2

2227800

Jeep® JK Wrangler Rear Mako Rear Bumper

1) REMOVE YOUR FACTORY BUMPER

Begin by removing your factory bumper.

With a 16mm Socket, remove the 2 bolts from each side of your frame bracket.



Remove the 2 16mm bolts from the rear crossmember.



Remove the 2 16mm bolts between the body and bumper.



If your vehicle comes with a recovery hook, it will need to be uninstalled by removing the 3 18mm bolts.



2) INSTALL YOUR BUMPER

Insert the nut plates into your Jeep's frame rails so that the holes line up with the outside of the frame.



With the help from a second pair of hands, lift the bumper up to the frame of the Jeep. Using a short 12mm bolt, lock washer, and washer, loosely fasten the bumper brackets to your frame rail. Do not tighten yet, as you may need to adjust the bumper when installing the other bolts.





INSTALLATION INSTRUCTIONS

PART No.

FB22278

**Jeep® JK Wrangler
Rear Mako Rear Bumper**

- 3) **TIGHTEN ALL BOLTS.**
- 4) **MOUNT THE SUPPLIED D-RINGS**
- 5) **ENJOY YOUR NEW FISHBONE OFFROAD BUMPER!**

