

## Tools Required

- Lint free cloth
- Glass Cleaner
- Spray bottle.
- Felt edge squeegee or shower squeegee
- Sharp scalpel or stanley knife for trimming, these can also be used for scraping stubborn marks off your window prior to application.



## Window Film No Application Tape Application Instructions

### Preparation:

Before starting, thoroughly inspect your window. Use a scraper to remove any loose particles, fibres, paint spots, and irregular putty lines. This will ensure a smooth and clean surface for the film.

Clean the window using a glass cleaner. We recommend using Mr Muscle for best results. Ensure that the window is free from dirt, grease, and any other residues.

Avoid working on carpets or wearing clothes with loose fibres to prevent them from transferring onto the window film.

Before handling the film, make sure your hands are clean to avoid transferring oils or dirt onto the adhesive side of the film.

Do not touch the adhesive backing directly. The oils from your skin can interfere with the adhesive quality and may prevent the film from sticking properly.

Be cautious when removing the backing paper from the film. The adhesive is very sticky, and there is a risk of it sticking to itself.

We recommend applying internally but the film can be applied externally if required.

### Application:

Application fluid, make from water with a little washing up liquid in a spray bottle.  
(approx 1 pint of water, 2 drops of washing up liquid)

1. Spray your surface with plenty of application fluid.
2. Lay your film face down on a clean, dust free, flat surface. Carefully remove the backing paper and generously spray back of window film (sticky side) using a fine spray.
3. Holding the top two corners of your window film, carefully place onto your surface.
4. You will be able to manoeuvre the film into position, once in position lightly run your hand over the film to press into place.
5. Starting from the centre working outwards carefully run the squeegee over your film, squeezing the application fluid and bubbles out.
6. The film will be fully adhered after 24 hours.

Stand back and admire your work!

