



Sand and fill

Primer and chalk as a filler on Linseed oil paint

To achieve a high, finish in-doors on a painted surface you can mix chalk with Primer to a consistency of thick, paintable primer, similar to thinned putty.

- Mix primer with chalk.
- Apply with a brush.
- Let dry for about 30 minutes. With hot air, the drying time can be reduced to a few minutes.
- The filler can be sanded wet or dry and hardens all the way through without shrinkage cracks.
- The filler can be used on wood and plastered walls.
- Wet sand any wrinkles in the dry paint film with primer.

Linus as a filler

- Pour off the surface water. Mix in about 50% pumice powder.
- Fill wallpaper joints, irregularities or skim coat entire walls.
- Linus filler can be rolled on to the surface.
- Sand dry surface or wet sand semi-dry surface with damp sponge.
 - Finish painting 1 - 2 coats
 - Drying time about 24 hours.



Linus as a filler.