

Peacock Alley

BEDSKIRT DIAGRAM

An easy step-by-step process to apply and secure your Peacock Alley bedskirt.

Peacock Alley has developed a better way to install the perfect bedskirt. We manufacture our bedskirts in 3 panels. This makes the bedskirt easier to secure and set into place how you want it.

This package contains:

Three (3) separate bedskirt panels (Right Side Panel, Left Side Panel, Foot Panel)
and 8-L Shaped pins to secure panels

- 1** Press the bedskirt if necessary.
- 2** Remove the mattress to fully expose your box spring.
- 3** Begin with the shortest bedskirt panel at the foot of the bed. Affix the end of the panel to the corner edge of the box spring using the enclosed pins. *(Note to match the corner accurately for the cleanest look. Image A)*
- 4** Continue to attach the bedskirt to the box spring using pins every 12 inches. Place pins as far from the edge of the box spring as possible to avoid interference from your fitted sheet. *(Note if the panel is longer than the width of the box spring, fold under the extra length and fasten with a pin.)*
- 5** Next apply the first side panel. Begin at the same corner where you began with your foot panel. Match the length to the floor and the corner. Start at the foot of the bed and work towards the head securing pins. *(Image B)*
- 6** Repeat this same procedure with the third side panel, beginning at the foot of the bed and working towards the head. *(Image C)*
- 7** Finally, check the pins to ensure they are secure before lowering your mattress.

Any questions?

Please contact support@peacockalley.com
www.peacockalley.com

