



Canuck Homebrew Supply Presents

Barley's Brewing Book: Clamps, Hoses, & Disconnects

You Will Need:

A Heat Source (hot water, heat gun, hairdryer, etc.)
Needle Nosed Pliers

* Slide the hose clamps onto the hose first

1. Heat the end of your hose until it becomes pliable.
2. Insert needle nosed pliers into the end of the hose and slowly stretch it.
3. When the hose end is widened enough, insert the barb of your disconnect into the end of the hose, far enough that the hose clamp will be able to hold the hose onto the barb.
4. Slide the hose clamp to where the barb and hose overlap, making sure the clamp covers both the hose and barb, and crimp the clamp until it is fully crimped.

* Always slide your hose clamps onto the hose first, you won't be able to after the hose is stretched.