



Adventure Rack – Mid Height Installation

Tools Required:

- 15mm socket and wrench
- 9/16" socket and wrench
- Ratchet

Step 1: Place the base plate on the bed side as pictured to the right.



Step 2: Attach backer to base plate with angle facing down and towards the base as pictured to the right. Do not tighten.



Step 3: Attach side panel to base plate as pictured below. Do not tighten.



Step 4: Attach cross bars to side panel as pictured below. Do not tighten.

Step 5: Measure base plates to make sure both sides are equal distance front to rear on the bed sides. Tighten hardware with 15mm socket and wrench.

Step 6: Measure cross bars to make sure both sides are equal distance side to side on the side panels. Tighten hardware with 9/16" socket and wrench.



Step 7: Enjoy!

Load Capacity

Dynamic: 250 lbs

Static: 650 lbs