

Jack Mount Installation

Tools Required:

- ¾" socket and wrench
- Adjustable wrench
- Ratchet

Reference: Use these pictures as reference for the order of assembly.



Step 1: After determining which side of the bed you would like your jack mount located, pinch the top of the bed rail under the plastic rail and attach the bottom mount to the bed loop as seen in the pictures to the right. Tighten bolts to secure the mount.

Step 2: Mount the other end the same way by pinching the bed rail as seen in the picture to the right. Adjust the foot pad as needed to square the mount to the bed side. Tighten bolts to secure the mount.

