

JK GGB INSTALLATION INSTRUCTIONS



PARTS LIST

	QTY
Cargo basket deck	1
Clamps	2
Clamp to Platform Bracket	2 (1 right and 1 left hand bracket)
1/4" Washer	12
1/4" Wing Nut	6
1/4-20 x 1.0" Socket Cap Bolt	8
1/4-20 x 1/2" Flange Bolt	8
1/4-20 x 1/2" Hex Bolt	6

REQUIRED TOOLS

7/16" Socket & Ratchet
7/16" Open End Wrench
3/16" L Hex Key or equivalent
Anti-Seize

PLEASE READ BEFORE BEGINNING INSTALLATION

Prior to starting the installation of this product we suggest reading the entire instruction manual. Several of the steps involved in installation of this product are fairly complex and reading through ahead of time will help you with a pain free installation. An extra minute or two spent now will save a lot of headache down the road.

This product must be installed by someone with a certain amount of mechanical aptitude. Vector OffRoad can not be held liable for damage caused to your vehicle due to poor or incomplete installation of this product. If you have any questions, are missing parts or need help locating a skilled installation shop in your area please contact us.

1. Assemble the left and right hand platform brackets loosely to the cargo basket using six 1/4" hex head bolts, six washers, and six wing nuts. The brackets can be mounted at different heights to adjust the basket clearance height. Keep the hardware as loose as possible at this point to allow for further adjustments.

2. Unzip and pull back both sides of your rear roll bar padding.

3. Mount the clamps to the rear roll cage bars 4.5" below the center of the seat belt bung. Put anti-seize (important) on the leading edge of the threads of all the bolts. Keep the clamps as loose as possible at this time to allow for minor adjustments. The flat clamp faces with the tapped holes should both face each other, toward the center of the jeep.



4. Pull the roll bar padding back around the clamps (Leave unzipped). The velcro opening in the padding should align with the mounting face of the clamps. A second person or something to support the basket is helpful for the following step. Lift the basket into place and fasten both brackets to the clamps using eight 1/4-20 x 1/2" Flange head bolts. Keep the hardware loose at this time.

5. Check the alignment of all the parts and make sure that the platform is level before beginning to torque the fasteners. Do not over torque the fasten-

6. Torque Specs:

- A. Clamp Bolts 15 ft-lbs
- B. Bracket to Clamp Flange Bolts 15 ft-lbs
- C. Bracket to Platform Bolts 15 ft-lbs

7. Reclose the roll bar padding zippers.

Questions or Comments, please email admin@vectoroffroad.com