

2019 Powerstroke front valance installation instructions

Tools required:

- 8mm Ratchet
- Extension
- Optional: Swivel Head

Before you start

- Confirm All Parts Are Present
- Read Installation Guide
- Clean the truck to avoid dirt and rocks being caught in the valance and scratching during disassembly/assembly



Valance Install

Step One: Start removing the 11 bolts on the underside of the valance from the outsides towards the inside



Step Two: Once you are left with one bolt in the center supporting the valance, use one hand to remove the final bolt while your other holds the valance up



Step Three: With the new valance, start installing the new bolts from the inside out, leaving them slightly loose so you can align all 11



Step Four: Once all 11 bolts have been threaded in, tighten them snug



Step Five: You're all done! Enjoy your new valance!

