

Step 1 - Install RAINPOD & place water butts into position

Step 2 - Replace water butt tap

Simply replace your existing water butt taps with the 90 degree fast bend connectors provided.

If you want to keep your water butt taps, simply cut a new hole with a 25mm hole saw. For textured water butts, you may need some additional sealant to provide a water tight seal.



Step 3 - Connect RAINPOD & stretch out hose

Connect to your RAINPOD using the jumbo click connector. Ensure you have tightened the connector firmly to the hose then click into place.

Pull hose and stretch it out, ensure there are no kinks or twisted. As the hose has been coiled up for some time in the warehouse, you may need to untwist to straighten it out.

Pull hose all the way in front of all water butt and cut off excess. .

The hose will plump out over a short time when filled with water.



Step 4 - Connect to your water butt

We recommend connecting to your last water butt or furthest water butt away first.

Place jubilee clip onto your hose, slip hose over connector and tighten jubilee clip firmly.

