

4 CUBBY



Included


24 Pins




4 Vertical Side zBoards (groove on 1 side) 2 Vertical Middle zBoards (groove on 2 sides)



1 Top zBoard, 1 Bottom zBoard (Groove on 1 side)



1 Middle zBoard (Groove on 2 sides)



4 Backboards

WARNING: CHOKING HAZARD
Small parts NOT for children under 3 years

Important



THIS SIDE UP

CAUTION placing unit on its side or back will compromise structural integrity. Use right side up.



- Assemble your unit on a flat even surface
- Make sure zBoard surfaces are clean and dry

- When moving your Way Basics unit, lift from the bottom
- Indoor use only. Not in bathroom.

- Carefully remove the 3M protective layer from adhesive (adhesive shown in yellow).
- Place alignment pins in vertical zBoards.
- Align vertical middle zBoard to horizontal zBoard and press down firmly. Insert backboards into grooves.
- Align vertical side zBoards with grooves facing the backboard.
- Align middle horizontal zBoard (has grooves on top and bottom) and press down firmly.
- Align vertical middle zBoard to horizontal zBoard and press down firmly. Insert backboards into grooves.
- Align vertical side zBoards with grooves facing the backboard.
- Align top horizontal zBoard to unit and press down firmly.

Enjoy building possibilities!

