

# Little COLORADO™

## Modern Wooden Toddler Furniture

### Montessori Furniture Assembly Instructions Toddler Desk Conversion Kit (20" or 30" wide)

#### Hardware and Wood Parts:

- 1 – Foot Rest shelf (U-shaped shelf with two holes pre-drilled into each shelf end).
- 1 – Desk Shelf (wider lipped shelf with two holes pre-drilled into each shelf end)
- 8 – 2" Confirmat construction screws
- 1 – Allen Wrench



#### Assembly Instructions

1. Confirm you have all the parts listed above. If any parts are missing, incorrect or damaged, please contact us right away. Once all parts are confirmed, clear a flat space on the floor or on a large level table to begin assembly. This kit requires that you already have a Montessori shelf unit from a previous purchase that will be retrofitted. **Please disassemble your original unit prior to Step 2.**
2. Insert one end of the Foot Rest Shelf into the middle dado of one side panel. Insert a 2" Confirmat screw through the hole in the side panel and into the pre-drilled hole in the shelf end. Use the Allen wrench to tighten the screw until 1 full turn remains ...do not completely tighten the screw at this time. Repeat on that same end of the shelf with a second Confirmat screw and tighten the screw until 1 full turn remains ...do not completely tighten the Confirmat screw at this time.
3. Now install the Desk Shelf into the upper dado as in Step 2 above, making sure the wider lipped extension edge is towards the front of the unit. **NOTE:** The Desk Shelf can be installed in two ways: (1) with the long pencil/crayon dado on the top side of the shelf if it is to be used for pencil storage, OR (2) flipped over so there is no pencil/crayon holder but rather a solid flat desk surface on the top...that is your personal choice. Either way, be sure that once you have decided which surface of the Desk Shelf you want up, make sure the wider lipped edge is facing the front of the unit.
4. Now take the remaining side panel and place it near the ends of the two shelves and fit the shelves into the two dados. Starting from the bottom dado, install two Confirmat screws into each shelf as in Step 2 above, being sure that each shelf remains seated in the dados prior to tightening as in Step 2.
5. With the two shelves aligned and secured inside the dados, stand the unit up on a level flat surface. With the Allen wrench, finish tightening all eight Confirmat screws, again confirming that all shelves are inside all dados of each side panel. Once this is completed.....congratulations! You are now done! We hope you and your child enjoy this unit for years to come.