

KevinsOffroad.com
Installation Guide for WJ A-Arm Spacer

1. Using a 21mm end wrench, remove the 3 bolts that secure the upper arm to the differential.



2) Remove the e-brake and brake line cable from the upper a-arm using a 10mm socket to allow the a-arm to be raised enough to allow installation of a-arm spacer. Re-install the upper a-arm bracket using the supplied 14mm x 100mm (approx 4") bolts from Hardware kit. Tighten using a 22mm socket or end wrench.

